





































**Originalfernbedienung Ersatzfernbedienung**

	Standby		Power
	Mute		Mute / Dimmer
	Play / Size		Play / Slow
	Pause /		Pause / Step / Freeze
	Stop / Hold		Stop / Hold
	<<		<< / Tune-
	>>		>> / Tune+
	I<<		I<< / Preset-
	>>I		>>I / Preset+
	S.Mode		Sound / Title
	Audio		Audio / Lang I/II
	Subtitle		Subtitle / EQ
	Pic. Mode		Picture / Format
	Sleep		Sleep / Timer
	TV / Radio		TV/Radio /
	Index		D.Menu / Top
	Text		Text / Goto

**Originalfernbedienung Ersatzfernbedienung**

	Source		AV / Input / RDS
	Menu		Menu / Home
	Up		Up
	Left		Left
	OK		OK
	Right		Right
	Exit		Exit / Cancel / Clear
	Down		Down
	Recall		Back / Return
	Vol+		Vol+
	CH. List		Smart / List
	CH+		CH+ / Page+
	Vol-		Vol-
	Display		Display / Media
	CH-		CH- / Page-
	1		1
	2		2



