



Original		Replacement		Original		Replacement	
	Power		Power		Remain		Smart
	DVD		Blue		Cancel		Media
	Tuner		Green		I<<		I<<
	USB		Yellow		>>I		>>I
	AUX		Red		<<		<<
	Open/Close		Eject		>>		>>
	Sleep		Sleep		Stop		Stop
	1		1		Play		Play
	2		2		Pause		Pause
	3		3		Step		Options
	4		4		Repeat		Text
	5		5		Vol+		Vol +
	6		6		Vol-		Vol -
	7		7		Mute		Mute
	8		8		Tuning Up		Ch +
	9		9		Tuning Down		Ch -
	0		0		Menu		Menu



