





Original	Replacement
 Mute	 Mute / Dimmer
 Power	 Power
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 ✓	 Guide / EPG / -/--
 0	 0
 Red / <<<	 Red / Netflix / Search
 Red / <<<	 <<< / Tune-
 Green / Stop	 Green / APP / Repeat
 Green / Stop	 Stop / Hold

Original	Replacement
 Yellow / Play	 Play / Slow
 Yellow / Play	 Yellow / YouTube / Repeat
 Blue / >>>	 >>> / Tune+
 Blue / >>>	 Blue / Prime Video / Random
 Up	 Up
 Left	 Left
 OK	 OK
 Right	 Right
 Down	 Down
 SFI	 D.Menu / Top
 Exit / Recall	 Back / Return
 Exit / Recall	 Exit / Cancel / Clear
 Info	 Info / Angle
 Prog +	 CH+ / Page+
 TV / Radio	 TV/Radio /
 Vol +	 Vol+
 Prog -	 CH- / Page-






Original	Replacement
Menu	Menu / Home
Vol -	Vol-
TV/SAT	Smart / List
TXT	Text / Goto
Stop	Pause / Step / Freeze
EXT	Display / Media
SAT1 + OK	Shift + 2
SAT2 + OK	Shift + 3
TV + OK	Shift + 1
PIP	Picture / Format

Original	Replacement







Original	Replacement	
	Mute	 Mute / Dimmer
	Power	 Power
	1	 1
	2	 2
	3	 3
	4	 4
	5	 5
	6	 6
	7	 7
	8	 8
	9	 9
	✓	 Guide / EPG / -/--
	0	 0
	A/B	 Shift + Yellow / YouTube /
	Red / <<<	 <<< / Tune-
	Red / <<<	 Red / Netflix / Search
	Green / Stop	 Green / APP / Repeat

Original	Replacement	
	Green / Stop	 Stop / Hold
	Yellow / Play	 Play / Slow
	Yellow / Play	 Yellow / YouTube / Repeat
	Blue / >>>	 >>> / Tune+
	Blue / >>>	 Blue / Prime Video / Random
	Up	 Up
	Left	 Left
	OK	 OK
	Right	 Right
	Down	 Down
	SFI	 D.Menu / Top
	Exit / Recall	 Exit / Cancel / Clear
	Exit / Recall	 Back / Return
	Info	 Info / Angle
	Prog +	 CH+ / Page+
	TV / Radio	 TV/Radio /
	Vol +	 Vol+





















Original		Replacement	
	Prog -		CH- / Page-
	Menu		Menu / Home
	Vol -		Vol-
	TV/SAT		Smart / List
	TXT		Text / Goto
	Stop		Pause / Step / Freeze
	EXT		Display / Media
	SAT1 + OK		Shift + 2
	SAT2 + OK		Shift + 3
	TV + OK		Shift + 1

Original		Replacement	







Original	Replacement
 Mute	 Mute / Dimmer
 Power	 Power
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 ✓	 Guide / EPG / -/--
 0	 0
 A/B	 Shift + Yellow / YouTube /
 Red / <<<	 Red / Netflix / Search
 Red / <<<	 <<< / Tune-
 Green / Stop	 Stop / Hold

Original	Replacement
 Green / Stop	 Green / APP / Repeat
 Yellow / Play	 Play / Slow
 Yellow / Play	 Yellow / YouTube / Repeat
 Blue / >>>	 >>> / Tune+
 Blue / >>>	 Blue / Prime Video / Random
 Up	 Up
 Left	 Left
 OK	 OK
 Right	 Right
 Down	 Down
 SFI	 D.Menu / Top
 Exit / Recall	 Back / Return
 Exit / Recall	 Exit / Cancel / Clear
 Info	 Info / Angle
 Prog +	 CH+ / Page+
 TV / Radio	 TV/Radio /
 Vol +	 Vol+



