
























Originalfernbedienung Ersatzfernbedienung

	Power		Power
	Mute		Mute
	Source		AV
	Radio		TV/R
	Still		Smart
	List		List
	Aspect		3D
	EPG		Guide
	O)/I/II/Audio		Dual
	FAV+		Shift + Up
	FAV-/Repeat		Shift + Down
	Info		Info
	Sleep		Sleep
	PIC		Format
	Sound		Shift + Dual
	Menu		Menu
	Exit		Exit

Originalfernbedienung Ersatzfernbedienung

	Up		Up
	Down		Down
	Right		Right
	Left		Left
	Enter		Ok
	CH+		Ch +
	CH-		Ch -
	Vol+		Vol +
	Vol-		Vol -
	Recall		Pre Ch
	Text		Text
	<<		<<
	>>/Mix		>>
	Play		Play
	Pause/Index		Pause
	I<</Hold		I<<
	>>I/Size		>>I



