















Originalfernbedienung Ersatzfernbedienung

	Power		Power
	Play		Play
	Pause		Pause
	<<		<<
	>>		>>
	I<<		I<<
	>>I		>>I
	Stop		Stop
	Rec		Rec
	Tv/TXT		Text
	Cancel		Shift + Exit
	Hold		Options
	Reveal		D. Menu
	Size		3D
	Red		Red
	Green		Green
	Subpage		Eject

Originalfernbedienung Ersatzfernbedienung

	Yellow		Yellow
	Index		List
	Blue		Blue
	CH+		Ch +
	CH-		Ch -
	Input		AV
	Vol+		Vol +
	Vol-		Vol -
	Mute		Mute
	Menu		Menu
	Exit		Exit
	DVB		Smart
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	OK		Ok





Originalfernbedienung	Ersatzfernbedienung	Originalfernbedienung	Ersatzfernbedienung
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	-/--	+	Shift + Guide
	Recall		Back
	Picture	+	Shift + Format
	Sound	+	Shift + Dual
	Nicam/A2		Media
	Sleep		Sleep
	Tv/Radio		TV/R

