




















Originalfernbedienung	Ersatzfernbedienung
 Power	 Power
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0 / AV	 0
 0 / AV	 AV
 i	 Info
 Mute	 Mute
 Up / P+	 Ch +
 Up / P+	 Up
 Down / P-	 Ch -

Originalfernbedienung	Ersatzfernbedienung
 Down / P-	 Down
 Right / Vol +	 Vol +
 Right / Vol +	 Right
 Left / Vol -	 Vol -
 Left / Vol -	 Left
 OK	 Ok
 Aux	 Media
 Txt	 Text
 Red	 Red
 Green	 Green
 Yellow	 Yellow
 Blue	 Blue
 Contrast -	 I<<
 Contrast +	 >>I
 Brightness -	 <<
 Brightness +	 >>



