
























Originalfernbedienung Ersatzfernbedienung

	Power		Power
	Sleep		Sleep
	Mute		Mute
	Timer		AV
	EPI		Guide
	SUBTL		Subt
	Audio		Shift + Dual
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0

Originalfernbedienung Ersatzfernbedienung

	16:9		Format
	Lang		Dual
	RCL		Back
	FAV		Pre Ch
	Page+ / Timeshift		Shift + Ch +
	Page- / V-Format		Shift + Ch -
	Page- / V-Format		Shift + Format
	Up / CH+		Up
	Up / CH+		Ch +
	Down / CH-		Down
	Down / CH-		Ch -
	Right / Vol+		Right
	Right / Vol+		Vol +
	Left / Vol-		Left
	Left / Vol-		Vol -
	OK		Ok
	Menu		Menu



