





































Originalfernbedienung Ersatzfernbedienung

	Power		Power
	Picture Size		Eject
	Picture Mode		Format
	Sound Select		Dual
	PIP On		Smart
	PIP Size		Shift + Eject
	PIP CH+		Shift + Ch +
	PIP CH-		Shift + Ch -
	PIP Source		Shift + AV
	PIP Swap		Shift + Back
	Up / CH+		Up
	Up / CH+		Ch +
	Down / CH-		Down
	Down / CH-		Ch -
	Right / Vol+		Right
	Right / Vol+		Vol +
	Left / Vol-		Left

































Originalfernbedienung Ersatzfernbedienung

	Left / Vol-		Vol -
	OK		Ok
	Menu		Menu
	Source		AV
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	Still		Pause
	Prev CH		Back
	Mute		Mute





Originalfernbedienung Ersatzfernbedienung

	Info		Info
	CH Scan		Media
	Text On		Text
	Text Mix		Shift + 1
	Text Index		Shift + 2
	Text Hold		Shift + 3
	Text Subpage		Shift + 4
	Text Size		Shift + 5
	Text Reveal		Shift + 6
	Text Store		Shift + 7
	Text List		Shift + 8
	Red / Auto CH		Red
	Green / Add/Erase		Green
	Yellow / MTS		Yellow
	Blue / Sleep		Blue
	Blue / Sleep		Sleep

Originalfernbedienung Ersatzfernbedienung

