






















































Originalfernbedienung Ersatzfernbedienung

	Power		Power
	SD/HC		Shift + Display / Media
	Input TV		Shift + AV / Input / RDS
	Input AV		AV / Input / RDS
	Aspect		Picture / Format
	Menu		Menu / Home
	N		Shift + Up
	Direct Tv Rec		D.Menu / Top
	i		Info / Angle
	Exit		Exit / Cancel / Clear
	Viera Tools		Smart / List
	Viera Link		Display / Media
	Up		Up
	Guide		Guide / EPG / -/-
	Left		Left
	OK		OK
	Right		Right

Originalfernbedienung Ersatzfernbedienung

	Option		Setup / OPT /
	Down		Down
	Return		Back / Return
	Red		Red / Netflix / Search
	Green		Green / APP / Repeat
	Yellow		Yellow / YouTube / Repeat
	Blue		Blue / Prime Video / Random
	Text		Text / Goto
	[≡♦]/Sttl		Subtitle / EQ
	[≡i]/Index		Shift + Info / Angle
	[≡+]/Hold		Shift + Stop /
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6





Originalfernbedienung Ersatzfernbedienung

	7		7
	8		8
	9		9
	Mute		Mute / Dimmer
	0		0
	OIO	+	Shift + Smart / List
	Vol+		Vol+
	CH+		CH+ / Page+
	Vol-		Vol-
	CH-		CH- / Page-
	Power Down	+	Shift + Power
	Programme	+	Shift + CH- /
	Programme Up	+	Shift + CH+ /
	<</I<<		<< / Tune-
	Play		Play / Slow
	>>/>>I		>> / Tune+
	Stop		Stop / Hold

Originalfernbedienung Ersatzfernbedienung

	Pause/Step		Pause / Step / Freeze
	Rec		Rec / Rec Mode

