







































































**Originalfernbedienung    Ersatzfernbedienung**

	Power		Power
	TV - Gids		List
	Extra		Options
	Comm.		Subt
	TV - Theek		Dual
	Home		Smart
	Mute		Mute
	Help		Info
	Vol+		Vol +
	Vol-		Vol -
	CH+		Ch +
	CH-		Ch -
	Up		Up
	Left		Left
	OK		Ok
	Right		Right
	Down		Down

**Originalfernbedienung    Ersatzfernbedienung**

	Delete		3D
	Exit		Exit
	Back		Back
	<<		<<
	>>		>>
	Pause		Pause
	Play		Play
	Rec		Rec
	Stop		Stop
	Text		Text
	Red		Red
	Green		Green
	Yellow		Yellow
	Blue		Blue
	1		1
	2		2
	3		3







