










































Originalfernbedienung Ersatzfernbedienung

	Power		Power
	Standby	 + 	Shift + Power
	Tuner		1
	CD		2
	CD-R		3
	DTV		4
	CBL/SAT		5
	MD/Tape		6
	Net/USB		7
	VCR 1		8
	DVR/VCR 2		9
	DVD		Guide
	V-AUX/Dock		0
	Preset Up		Ch +
	Preset Down		Ch -
	A/B/C/D/E		Smart
	Vol+		Vol +

Originalfernbedienung Ersatzfernbedienung

	Vol-		Vol -
	Mute		Mute





Originalfernbedienung Ersatzfernbedienung

	Power		Power
	Standby		Shift + Power
	Tuner		1
	CD		2
	CD-R		3
	DTV		4
	CBL/SAT		5
	MD/Tape		6
	Net/USB		7
	VCR 1		8
	DVR/VCR 2		9
	DVD		Guide
	V-AUX/Dock		0
	Preset Up		Ch +
	Preset Down		Ch -
	A/B/C/D/E		Smart
	Vol+		Vol +



































Originalfernbedienung Ersatzfernbedienung

	Vol-		Vol -
	Mute		Mute









Originalfernbedienung Ersatzfernbedienung

	Power		Power
	Standby		Shift + Power
	Tuner		1
	CD		2
	CD-R		3
	DTV		4
	CBL/SAT		5
	MD/Tape		6
	Net/USB		7
	VCR 1		8
	DVR/VCR 2		9
	DVD		Guide
	V-AUX/Dock		0
	Preset Up		Ch +
	Preset Down		Ch -
	A/B/C/D/E		Smart
	Vol+		Vol +




































Originalfernbedienung Ersatzfernbedienung

	Vol-		Vol -
	Mute		Mute









Originalfernbedienung Ersatzfernbedienung

	Power		Power
	Standby	 + 	Shift + Power
	Tuner		1
	CD		2
	CD-R		3
	DTV		4
	CBL/SAT		5
	MD/Tape		6
	Net/USB		7
	VCR 1		8
	DVR/VCR 2		9
	DVD		Guide
	V-AUX/Dock		0
	Preset Up		Ch +
	Preset Down		Ch -
	A/B/C/D/E		Smart
	Vol+		Vol +

Originalfernbedienung Ersatzfernbedienung

	Vol-		Vol -
	Mute		Mute

