





































Original	Replacement
 Power	 Power
 Source	 AV
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 TTX/MIX	 Text
 PRE-CH	 Pre Ch
 Mute	 Mute
 CH List	 List
 Vol+	 Vol +

Original	Replacement
 Vol-	 Vol -
 CH+	 Ch +
 CH-	 Ch -
 Settings	 Options
 Home	 Smart
 Guide	 Guide
 Info	 Info
 Rec	 Rec
 Enter	 Ok
 Up	 Up
 Down	 Down
 Left	 Left
 Right	 Right
 Return	 Back
 Exit	 Exit
 Red	 Red
 Green	 Green



