






















































































Original	Replacement	Original	Replacement
	 Eject / Surround		 3
	 +  Shift + Power		 +  Shift + 3
	 Power		 +  Shift + Setup / OPT / Tools
	 +  Shift + Sound / Title		 Audio / Lang I/II
	 AV / Input / RDS		 4
	 +  Shift + Mute / Dimmer		 +  Shift + 4
	 Green / APP / Repeat		 5
	 TV/Radio /		 +  Shift + 5
	 Exit / Cancel / Clear		 6
	 +  Shift + D.Menu / Top Menu		 +  Shift + 6
	 Sleep / Timer		 Picture / Format
	 Mute / Dimmer		 Info / Angle
	 Play / Slow		 7
	 1		 +  Shift + 7
	 +  Shift + 1		 8
	 2		 +  Shift + 8
	 +  Shift + 2		 9





Original	Replacement	Original	Replacement
 9 TV	 Shift + 9	 <<	 << / Tune-
 Sound Field	 Sound / Title	 >>	 >> / Tune+
 Subtitle	 Subtitle / EQ	 Play/Select	 Shift + Play /
 >10	 Guide / EPG / -/--	 Pause	 Pause / Step / Freeze
 >10 TV	 Fav / Marker / PC	 Stop	 Stop / Hold
 0/10	 0	 DVD Display	 Shift + Display / Media
 0/10 TV	 Shift + 0	 DVD Top Menu	 Menu / Home
 Enter	 Shift + OK	 Up	 Up
 Display	 Display / Media	 DVD Menu	 D.Menu / Top
 Vol+	 Vol+	 Return	 Back / Return
 Vol+ Tv	 Shift + Vol+	 Left	 Left
 Vol-	 Vol-	 OK	 OK
 Vol- Tv	 Shift + Vol-	 Enter TV	 Shift + Down
 I<<	 I<< / Preset-	 Right	 Right
 I<< TV	 Shift + I<< / Preset-	 DVD Setup	 Setup / OPT /
 >>I	 >>I / Preset+	 AMP Menu	 Shift + Menu /
 >>I TV	 Shift + >>I / Preset+	 Down	 Down

