













































Original	Replacement	Original	Replacement
 Power	 Power	 CH-	 CH- / Page-
 TV / AV	 AV / Input / RDS	 Exit	 Exit / Cancel / Clear
 TV/TXT	 Text / Goto	 Vol-	 Vol-
 Cancel	 Shift + Exit / Cancel / Clear	 Up	 Up
 Reveal	 Display / Media	 Left	 Left
 DTV	 D.Menu / Top	 OK	 OK
 Hold	 Stop / Hold	 Right	 Right
 Size	 Shift + Zoom /	 Down	 Down
 Subpage	 Eject / Surround	 1	 1
 Index	 Smart / List	 2	 2
 Red	 Red / Netflix / Search	 3	 3
 Green	 Green / APP / Repeat	 4	 4
 Yellow	 Yellow / YouTube / Repeat	 5	 5
 Blue	 Blue / Prime Video / Random	 6	 6
 CH+	 CH+ / Page+	 7	 7
 Menu	 Menu / Home	 8	 8
 Vol+	 Vol+	 9	 9

Original	Replacement	Original	Replacement
 CH-	 CH- / Page-	 CH- / Page-	 CH- / Page-
 Exit	 Exit / Cancel / Clear	 Vol-	 Vol-
 Vol-	 Vol-	 Up	 Up
 Up	 Up	 Left	 Left
 Left	 Left	 OK	 OK
 OK	 OK	 Right	 Right
 Right	 Right	 Down	 Down
 Down	 Down	 1	 1
 1	 1	 2	 2
 2	 2	 3	 3
 3	 3	 4	 4
 4	 4	 5	 5
 5	 5	 6	 6
 6	 6	 7	 7
 7	 7	 8	 8
 8	 8	 9	 9
 9	 9		



