







Original	Replacement	Original	Replacement
	OFF	 + 	Shift + Power
	ON		Power
	Standard		Red / Netflix / Search
	Cinema		Green / APP / Repeat
	Music		Yellow / YouTube / Repeat
	DSP Simulation		Blue / Prime Video / Random
	Direct	 + 	Shift + Red / Netflix /
	Stereo	 + 	Shift + Green / APP /
	Virtual Surround	 + 	Shift + Yellow / YouTube /
	5CH/7CH Stereo	 + 	Shift + Blue / Prime
	Input PHONO		0
	Input CD		3
	Input TUNER		6
	Tuning+		>> / Tune+
	Input DVD/VDP		2
	Input TV/DBS		1
	Input VCR		4
	Tuning-		<< / Tune-
	Input VCR-2		9
	Input V.AUX		8
	Input CDR/TAPE		5
	Channel+ /		>> / Preset+
	Channel+ /		CH+ / Page+
	Input AUX		7
	Channel- / Preset-		<< / Preset-
	Channel- / Preset-		CH- / Page-
	Mode		Play / Slow
	Memory		Pause / Step / Freeze
	Band		Stop / Hold
	Shift		Rec / Rec Mode
	Vol+		Vol+
	Vol-		Vol-
	Muting		Mute / Dimmer
	Setup		Setup / OPT /





Original		Replacement		Original		Replacement	
	Up		Up				
	Surround		Eject / Surround				
	Left		Left				
	Enter		OK				
	Right		Right				
	Status / Display		Display / Media				
	Down		Down				
	Surround Back		Back / Return				
	Test Tone		Text / Goto				
	Video Select		Picture / Format				
	Dimmer		Shift + Mute / Dimmer				
	Speaker		Sound / Title				
	Input Mode		Shift + 1				
	Input Analog		Shift + 2				
	Input Ext.In		Shift + 3				

