





































Original	Replacement	Original	Replacement
Power	 Power	CH / Guide	 Guide / EPG / -/--
Recall	 Back / Return	Up	 Up
CC	 Subtitle / EQ	M	 Menu / Home
Text	 Text / Goto	A / CH	 Info / Angle
Smart	 Smart / List	Down	 Down
Sleep	 Sleep / Timer	Vol+	 Vol+
1	 1	Vol-	 Vol-
2	 2	Left / -	 Left
3	 3	Right / +	 Right
4	 4	Mute	 Mute / Dimmer
5	 5	CH+	 CH+ / Page+
6	 6	CH-	 CH- / Page-
7	 7	A	 Red / Netflix / Search
8	 8	B	 Green / APP / Repeat
9	 9	C	 Yellow / YouTube / Repeat
0	 0	D	 Blue / Prime Video / Random
Reset	 Exit / Cancel / Clear	G	 Shift + Yellow / YouTube / Repeat
















Original	Replacement	Original	Replacement
Clock	 +  Shift + Sleep / Timer		
E	 +  Shift + Red / Netflix		
F	 +  Shift + Green / APP		
A / V	 AV / Input / RDS		







Original	Replacement	Original	Replacement
Power	 Power		
Recall	 Back / Return		
CC	 Subtitle / EQ		
Text	 Text / Goto		
Smart	 Smart / List		
Sleep	 Sleep / Timer		
1	 1		
2	 2		
3	 3		
4	 4		
5	 5		
6	 6		
7	 7		
8	 8		
9	 9		
0	 0		
Reset	 Exit / Cancel / Clear		

Original	Replacement	Original	Replacement
Up	 Up		
CH / Guide	 Guide / EPG / -/--		
Down	 Down		
M	 Menu / Home		
Vol+	 Vol+		
A / CH	 Info / Angle		
Vol-	 Vol-		
Mute	 Mute / Dimmer		
Left / -	 Left		
Right / +	 Right		
CH+	 CH+ / Page+		
CH-	 CH- / Page-		
A	 Red / Netflix / Search		
B	 Green / APP / Repeat		
C	 Yellow / YouTube / Repeat		
D	 Blue / Prime Video / Random		
Clock	 Shift +  Sleep / Timer		























Original	Replacement	Original	Replacement
E	+  Shift + Red / Netflix /		
F	+  Shift + Green / APP /		
G	+  Shift + Yellow / YouTube /		
A / V	AV / Input / RDS		











Original	Replacement	Original	Replacement
Power	 Power		
Recall	 Back / Return		
CC	 Subtitle / EQ		
Text	 Text / Goto		
Smart	 Smart / List		
Sleep	 Sleep / Timer		
1	 1		
2	 2		
3	 3		
4	 4		
5	 5		
6	 6		
7	 7		
8	 8		
9	 9		
0	 0		
Reset	 Exit / Cancel / Clear		

Original	Replacement	Original	Replacement
CH / Guide	 Guide / EPG / -/--		
Up	 Up		
Down	 Down		
A / CH	 Info / Angle		
M	 Menu / Home		
Right / +	 Right		
Left / -	 Left		
Vol+	 Vol+		
Vol-	 Vol-		
Mute	 Mute / Dimmer		
CH+	 CH+ / Page+		
CH-	 CH- / Page-		
A	 Red / Netflix / Search		
B	 Green / APP / Repeat		
C	 Yellow / YouTube / Repeat		
D	 Blue / Prime Video / Random		
E	 Shift +  Shift + Red / Netflix / Search		





Original	Replacement	
F	 Shift + Green / APP /	
G	 Shift + Yellow / YouTube /	
Clock	 Shift + Sleep / Timer	
A / V	 AV / Input / RDS	

Original	Replacement	

