







































































Original		Replacement		Original		Replacement	
	Power		Power		Guide		Guide
	Mute		Mute		i		Info
	NTSC / PAL		Format		Menu		Menu
	Audio		Dual		Up / CH+		Up
	AV		AV		Down / CH-		Down
	1		1		Right / Vol+		Right
	2		2		Left / Vol-		Left
	3		3		OK		Ok
	4		4		Up / CH+		Ch +
	5		5		Down / CH-		Ch -
	6		6		Right / Vol+		Vol +
	7		7		Left / Vol-		Vol -
	8		8		↑		Shift + Ch +
	9		9		↓		Shift + Ch -
	0		0		Exit		Exit
	TV / Radio		TV/R		FAV		Pre Ch
	Recall		Back		SAT		Smart



