


























































































Original		Replacement		Original		Replacement	
	Power		Power		Input		AV / Input / RDS
	ATV/DTV		Smart / List		Digital Menu		D.Menu / Top
	Tv/DVD		Display / Media		DVD Menu		Menu / Home
	Eject		Eject / Surround		Top Menu		Shift + D.Menu / Top Menu
	1		1		Guide		Guide / EPG / -/-
	2		2		CH+		CH+ / Page+
	3		3		CH-		CH- / Page-
	4		4		Vol+		Vol+
	5		5		Vol-		Vol-
	6		6		Up		Up
	7		7		Down		Down
	8		8		Right		Right
	9		9		Left		Left
	0		0		Enter/CH List		OK
	Info		Info / Angle		Menu/Setup		Setup / OPT /
	Mute		Mute / Dimmer		Exit/Cancel		Exit / Cancel / Clear
	Tv/Radio		TV/Radio /		Return		Back / Return



Program



Original	Replacement
 Play	 Play / Slow
 Stop	 Stop / Hold
 I<<	 I<< / Preset-
 <</REV	 << / Tune-
 >>/FF	 >> / Tune+
 >>I	 >>I / Preset+
 Red/<I	 Red / Netflix / Search
 Green/Pause	 Green / APP / Repeat
 Yellow/Play Mode	 Yellow / YouTube / Repeat
 Blue/I>	 Blue / Prime Video / Random
 Marker	 Fav / Marker / PC
 Angle	 Shift + Info / Angle
 Repeat A-B	 Shift + Yellow / YouTube /
 Text	 Text / Goto
 Subtitle	 Subtitle / EQ
 Audio Select	 Audio / Lang I/II
 Zoom/CH RTN	 Zoom / Size

Original	Replacement
 Jump	 Sound / Title
 PIC Size	 Picture / Format
 Sleep	 Sleep / Timer

