





































































Original	Recharge
 Digital	 Display / Media
 Yellow/Theater Modes/Info	 Yellow / YouTube / Repeat
 Power	 Power
 Tv	 Shift + 1
 DVD	 Shift + 2
 Green/Stereo/[...]	 Green / APP / Repeat
 Blue/Delay/Title	 Blue / Prime Video / Random
 Red/Center/Audio	 Red / Netflix / Search
 Up	 Up
 Violet/Level/Came	 Fav / Marker / PC
 Tape	 Shift + 5
 SAT/CAB	 Shift + 0
 Tuner	 Shift + 6
 Video/VCR	 Shift + 4
 Left/-	 Left
 OK	 OK
 Right/+	 Right

Original	Recharge
 PTY	 Text / Goto
 Down	 Down
 Menu/RDS	 Menu / Home
 Vol+	 Vol+
 PR+ />>I	 CH+ / Page+
 Vol-	 Vol-
 PR- /I<<	 CH- / Page-
 Mute	 Mute / Dimmer
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9









































































Original	Rechange	Original	Rechange
 Memo / Clear	 Smart / List		
 0	 0		





Original	Recharge
 Digital	 Display / Media
 Yellow/Theater Modes/Info	 Yellow / YouTube / Repeat
 Power	 Power
 TV	 Shift + 1
 DVD	 Shift + 2
 Green/Stereo/[...]	 Green / APP / Repeat
 Blue/Delay/Title	 Blue / Prime Video / Random
 Red/Center/Audio	 Red / Netflix / Search
 Up	 Up
 Violet/Level/Came	 Fav / Marker / PC
 Tape	 Shift + 5
 SAT/CAB	 Shift + 0
 Tuner	 Shift + 6
 Video/VCR	 Shift + 4
 Left/-	 Left
 OK	 OK
 Right/+	 Right

Original	Recharge
 Down	 Down
 Menu/RDS	 Menu / Home
 Vol+	 Vol+
 PR+ />>I	 >>I / Preset+
 PR+ />>I	 CH+ / Page+
 Vol-	 Vol-
 PR- /I<<	 I<< / Preset-
 PR- /I<<	 CH- / Page-
 Mute	 Mute / Dimmer
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8





Original		Rechange	
	9		9
	Memo/Clear		Smart / List
	0		0
	<<		<< / Tune-
	Play		Play / Slow
	>>		>> / Tune+
	Rec		Rec / Rec Mode
	Stop		Stop / Hold
	Pause		Pause / Step / Freeze

Original		Rechange	





















Original	Recharge
Digital	Display / Media
Yellow/Theater Modes/Info	Yellow / YouTube / Repeat
Power	Power
TV	Shift + 1
DVD	Shift + 2
Green/Stereo/[...]	Green / APP / Repeat
Blue/Delay/Title	Blue / Prime Video / Random
Red/Center/Audio	Red / Netflix / Search
Up	Up
Violet/Level/Came	Fav / Marker / PC
Tape	Shift + 5
SAT/CAB	Shift + 0
Tuner	Shift + 6
Video/VCR	Shift + 4
Left/-	Left
OK	OK
Right/+	Right

Original	Recharge
PTY	Text / Goto
Down	Down
Menu/RDS	Menu / Home
Vol+	Vol+
PR+ />>I	CH+ / Page+
Vol-	Vol-
PR- /I<<	CH- / Page-
Mute	Mute / Dimmer
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
































































	Original	Rechange
	Memo/Clear	 Smart / List
	0	 0
	<<	 << / Tune-
	Play	 Play / Slow
	>>	 >> / Tune+
	Rec	 Rec / Rec Mode
	Stop	 Stop / Hold
	Pause	 Pause / Step / Freeze

Original	Rechange





























Original	Rechange
 Digital	 Display / Media
 Yellow/Theater Modes/Info	 Yellow / YouTube / Repeat
 Power	 Power
 Tv	 Shift + 1
 DVD	 Shift + 2
 Green/Stereo/[...]	 Green / APP / Repeat
 Blue/Delay/Title	 Blue / Prime Video / Random
 Red/Center/Audio	 Audio / Lang I/II
 Red/Center/Audio	 Red / Netflix / Search
 Up	 Up
 Violet/Camera/Le	 Fav / Marker / PC
 Tape	 Shift + 5
 SAT/CAB	 Shift + 0
 Tuner	 Shift + 6
 Video/VCR	 Shift + 4
 Left/-	 Left
 OK	 OK

Original	Rechange
 Right/+	 Right
 PTY	 Text / Goto
 Down	 Down
 Menu/RDS	 Menu / Home
 Menu/RDS	 AV / Input / RDS
 Vol+	 Vol+
 PR+ />>I	 CH+ / Page+
 PR+ />>I	 >>I / Preset+
 Vol-	 Vol-
 PR-/I<<	 CH- / Page-
 PR-/I<<	 I<< / Preset-
 Mute	 Mute / Dimmer
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5





Original	Rechange	Original	Rechange
	6		6
	7		7
	8		8
	9		9
	Memo/Clear		Smart / List
	0		0
	<<		<< / Tune-
	Play		Play / Slow
	>>		>> / Tune+
	Rec		Rec / Rec Mode
	Stop		Stop / Hold
	Pause		Pause / Step / Freeze

