





































Original	Rechange
 Standby	 Power
 Mute	 Mute / Dimmer
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 Aspect	 Shift + Picture / Format
 Recall	 Back / Return
 TVG	 Guide / EPG / -/-
 Subtitle	 Subtitle / EQ
 Audio	 Audio / Lang I/II

Original	Rechange
 Display	 Display / Media
 Tv/Radio	 Tv/Radio /
 Up	 Up
 Left	 Left
 OK	 OK
 Right	 Right
 Menu	 Menu / Home
 Down	 Down
 Exit	 Exit / Cancel / Clear
 FAV	 Fav / Marker / PC
 Vol+	 Vol+
 Vol-	 Vol-
 Rec	 Rec / Rec Mode
 CH+	 CH+ / Page+
 CH-	 CH- / Page-
 Media	 Shift + Display / Media
 Source	 AV / Input / RDS



