



Original	Rechange	Original	Rechange
Power	Power	Display	Info
VCR/DVD	Media	On Screen/Progressiv	3D
DVD Timer	Green	Top	Shift + Menu
VCR Timer	Red	Menu	Menu
1	1	Set Up	Options
2	2	Return	Back
3	3	Up	Up
4	4	Down	Down
5	5	Right	Right
6	6	Left	Left
7	7	Enter	Ok
8	8	I<</Previous	I<<
9	9	>>/Next	>>I
0/AUX	0	<</Slow-	<<
X/Cancel	Exit	Play/Select	Play
Showview/Video Plus+	Guide	>>/Slow+	>>
Prog/Check	Sleep	Stop/Clear	Stop

Original	Rechange	Original	Rechange
Power	Power	Display	Info
VCR/DVD	Media	On Screen/Progressiv	3D
DVD Timer	Green	Top	Shift + Menu
VCR Timer	Red	Menu	Menu
1	1	Set Up	Options
2	2	Return	Back
3	3	Up	Up
4	4	Down	Down
5	5	Right	Right
6	6	Left	Left
7	7	Enter	Ok
8	8	I<</Previous	I<<
9	9	>>/Next	>>I
0/AUX	0	<</Slow-	<<
X/Cancel	Exit	Play/Select	Play
Showview/Video Plus+	Guide	>>/Slow+	>>
Prog/Check	Sleep	Stop/Clear	Stop





Original		Rechange		Original		Rechange	
	Pause		Pause				
	Rec		Rec				
	Remain/Rec		Shift + Rec				
	←		Pre Ch				
	→		Blue				
	Angle/Live Check		AV				
	Subtitle		Subt				
	TV/DVD-TV/VCR		TV/R				
	Mute/Audio		Mute				
	PR+		Ch +				
	PR- TV/CBL/DVD		Ch -				
	Vol+ Tv		Vol +				
	Vol- Tv		Vol -				








Original		Rechange		Original		Rechange	
	Power		Power		Prog/Check		Sleep
	VCR/DVD		Media		Display		Info
	DVD Timer		Green		On Screen/Progressiv		3D
	VCR Timer		Red		Top		Shift + Menu
	1		1		Menu		Menu
	2		2		Set Up		Options
	3		3		Return		Back
	4		4		Up		Up
	5		5		Down		Down
	6		6		Right		Right
	7		7		Left		Left
	8		8		Enter		Ok
	9		9		I<</Previous		I<<
	0/AUX		0		>>/Next		>>I
	X/Cancel		Exit		<</Slow-		<<
	Memory/Mark		Smart		Play Select		Play
	Showview/Video Plus+		Guide		>>/Slow+		>>









































































Original		Recharge		Original	Recharge
	Stop/Clear		Stop		
	Pause		Pause		
	Rec		Rec		
	Remain/Rec		Shift + Rec		
	↔		Pre Ch		
	→		Blue		
	Angle/Live Check		AV		
	Subtitle		Subt		
	TV/DVD-TV/VCR		TV/R		
	Mute/Audio		Mute		
	PR+		Ch +		
	PR- TV/CBL/DVD		Ch -		
	Vol+ Tv		Vol +		
	Vol- Tv		Vol -		





Original	Rechange	Original	Rechange
 Power	 Power	 Menu	 Menu
 VCR/DVD	 Media	 Up	 Up
 DVD Timer	 Green	 Down	 Down
 VCR Timer	 Red	 Right	 Right
 1	 1	 Left	 Left
 2	 2	 Enter	 Ok
 3	 3	 I<</Previous	 I<<
 4	 4	 >>/Next	 >>I
 5	 5	 <</Slow-	 <<
 6	 6	 Play/Select	 Play
 7	 7	 >>/Slow+	 >>
 8	 8	 Stop/Clear	 Stop
 9	 9	 Pause	 Pause
 0/AUX	 0	 Rec	 Rec
 Prog/Check	 Sleep	 Remain/Rec	 Shift + Rec
 Display	 Info	 ↔	 Pre Ch
 Top	 Shift + Menu	 →	 Blue

Original	Rechange	Original	Rechange
 Menu	 Menu	 Up	 Up
 Down	 Down	 Right	 Right
 Left	 Left	 Enter	 Ok
 I<</Previous	 I<<	 >>/Next	 >>I
 <</Slow-	 <<	 Play/Select	 Play
 >>/Slow+	 >>	 Stop/Clear	 Stop
 Pause	 Pause	 Rec	 Rec
 Remain/Rec	 Shift + Rec	 ↔	 Pre Ch
 →	 Blue		





Original	Recharge
 Angle/Live Check	 AV
 Subtitle	 Subt
 PR+	 Ch +
 PR- TV/CBL/DVD	 Ch -
 Vol+ Tv	 Vol +
 Vol- Tv	 Vol -

Original	Recharge

