



Original	Rechange
 Power	 Power
 Mute	 Mute / Dimmer
 Play	 Play / Slow
 Pause/[≡]	 Pause / Step / Freeze
 Stop/[≡+]	 Stop / Hold
 Rec/[≡◆]	 Rec / Rec Mode
 <</[≡o]	 << / Tune-
 <</[≡i]	 << / Preset-
 >> /[≡?]	 >> / Preset+
 >>/[≡x]	 >> / Tune+
 Info	 Info / Angle
 OI/II/Audio	 Audio / Lang I/II
 [≡]	 Text / Goto
 ←/<x]	 Fav / Marker / PC
 1	 1
 2	 2
 3	 3

Original	Rechange
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 *	 Setup / OPT /
 0	 0
 Up	 Up
 [→]	 AV / Input / RDS
 Left	 Left
 OK	 OK
 Right	 Right
 Down	 Down
 Netflix	 Shift + Red / Netflix /
 YouTube	 Shift + Yellow / YouTube /
 Vol+	 Vol+








































































Original		Rechange		Original	Rechange
[Home]	Home / Source	[HOME]	Menu / Home		
[Up]	P+	[CH+]	CH+ / Page+		
[Vol-]	Vol-	[VOL]	Vol-		
[Down]	P-	[CH-]	CH- / Page-		
[Red]	Red	[NETFLIX]	Red / Netflix / Search		
[Green]	Green	[APP]	Green / APP / Repeat		
[Yellow]	Yellow	[YouTube]	Yellow / YouTube / Repeat		
[Blue]	Blue	[Prime Video]	Blue / Prime Video / Random		
[EPG]	EPG	[GUIDE]	Guide / EPG / -/--		
[LIST]	List	[LIST]	Smart / List		
[QMENU]	Q.Menu	[TOP MENU]	D.Menu / Top		





Original		Rechange		Original		Rechange	
	Power		Power		4		4
	Mute		Mute / Dimmer		5		5
	Play		Play / Slow		6		6
	Pause [/≡]		Pause / Step / Freeze		7		7
	Stop/[≡+]		Stop / Hold		8		8
	Rec/[≡◆]		Rec / Rec Mode		9		9
	<</[≡o]		<< / Tune-		*		Setup / OPT /
	<</[≡i]		<< / Preset-		0		0
	>> /[≡?]		>> / Preset+		[→]		AV / Input / RDS
	>> /[≡x]		>> / Tune+		Up		Up
	Info		Info / Angle		Left		Left
	O) /II/Audio		Audio / Lang I/II		OK		OK
	[≡]		Text / Goto		Right		Right
	←/<x]		Fav / Marker / PC		Down		Down
	1		1		Netflix		Shift + Red / Netflix /
	2		2		YouTube		Shift + Yellow / YouTube /
	3		3		Vol+		Vol+



