







































































Original		Recharge		Original		Recharge	
	On/Standby		Power		Display CD/USB		Info
	Open/Close		Eject		Stop CD		Stop
	1		1		Play/Pause CD		Play
	2		2		Equalizer		Dual
	3		3		X-Bass		Subt
	4		4		Memory		Rec
	5		5		Clear		Exit
	6		6		Clock/Timer		AV
	7		7		Sleep		Sleep
	8		8		Volume+		Vol +
	9		9		Volume-		Vol -
	0		0		Mute		Mute
	10+		Guide		Preset Up		Ch +
	Play Mode		Shift + Play		Preset Down		Ch -
	Display(Tv Out) iPod		TV/R		Tuning/Folder Up		>>
	Menu iPod		Menu		Tuning/Folder		<<
	Play/Pause iPod		Pause		Up		Up





Original	Recharge
Down	Down
Right/>>I	Right
Left/I<<	Left
Enter	Ok
iPod	Green
CD	Yellow
USB	Blue
AUX	Red
Tuner(Band)	Smart
ASPM RDS	Text
PTY RDS	3D
Display RDS	Format

Original	Recharge

