

































































Original	Rechange	Original	Rechange
 Power	 Power	 <<	 <<
 Bonusview	 Media	 >>	 >>
 Open / Close	 Eject	 Stop	 Stop
 1	 1	 Play	 Play
 2	 2	 Pause	 Pause
 3	 3	 Disc Menu	 D. Menu
 4	 4	 Menu	 Menu
 5	 5	 Popup / Title	 Shift + Menu
 6	 6	 Popup / Title	 List
 7	 7	 Tools	 Options
 8	 8	 Info	 Info
 9	 9	 Up	 Up
 0	 0	 Left	 Left
 Subtitle	 Subt	 Enter	 Ok
 Audio	 Dual	 Right	 Right
 <<	 <<	 Down	 Down
 >>	 >>	 Return	 Back





Original		Recharge		Original	Recharge
	Exit		Exit		
	Red		Red		
	Green		Green		
	Yellow		Yellow		
	Blue		Blue		
	Smart HUB		Smart		
	Search		TV/R		
	Repeat		Text		
	TV Power		Shift + Power		
	TV Source		AV		
	TV Vol +		Vol +		
	TV Vol -		Vol -		
	TV Mute		Mute		
	TV CH +		Ch +		
	TV CH -		Ch -		

