




Original	Recharge	Original	Recharge
 Power	 Power	 Return	 Back
 Program	 Sleep	 Angle	 Exit
 Subtitle/Copy	 Subt	 USB/Card	 Smart
 Open/Close	 Eject	 Up	 Up
 Display	 Shift + Info	 Down	 Down
 Step	 List	 Right	 Right
 ↔/A-B	 3D	 Left	 Left
 Repeat	 Shift + Text	 Enter	 Ok
 V-Mode	 Format	 Menu	 Menu
 N/P	 D. Menu	 Play	 Play
 PBC	 Shift + TV/R	 Pause	 Pause
 Zoom	 Shift + Eject	 Stop/PVR	 Stop
 Text/Title	 Text	 EPG	 Guide
 DVD/DVB	 AV	 Info	 Info
 Tv/Radio	 TV/R	 Vol+	 Vol +
 Audio	 Dual	 Vol-	 Vol -
 Setup	 Options	 Mute	 Mute



