




































Original	Recharge	Original	Recharge
On/Off	 Power	OK Enter	 Ok
Audio Off	 Mute	Menu Right	 Right
Slow Down	 Ch -	Return	 Exit
Stop	 Stop	Menu Down	 Down
Slow Up	 Ch +	Top Menu	 D. Menu
Auto/Track	 Smart	Progr.	 Back
Rep/A-B	 +  Shift + Text	Volume+	 Vol +
Subt.	 Subt	Next	 >>
Title	 List	Volume-	 Vol -
Repeat/1/All	 Text	Prev.	 <<
Pause	 Pause	1	 1
Zoom	 Eject	2	 2
Display	 Info	3	 3
DVD/TV	 AV	4	 4
Menu	 Menu	5	 5
Menu Up	 Up	6	 6
Menu Left	 Left	7	 7



