






















































	Original	Rechange		Original	Rechange
	Power		Power		PR-
	Red		Red		1
	Green/Cass.		Green		2
	Yellow/Prog		Yellow		3
	Blue/Mem		Blue		4
	Violet/Status		Smart		5
	Exit		Exit		6
	Menu		Menu		7
	Up		Up		8
	Down		Down		9
	Right		Right		0
	Left		Left		AV
	OK		Ok		Index/Mark
	Vol+		Vol +		0000
	Vol-		Vol -		SP/LP
	Mute		Mute		<<
	PR+		Ch +		Play



















































	Original	Rechange	Original	Rechange
	>>	 >>		
	Rec	 Rec		
	Stop	 Stop		
	Pause	 Pause		





	Original	Recharge		Original	Recharge
	Power		Power		PR-
	Red		Red		1
	Green/Cass.		Green		2
	Yellow/Prog		Yellow		3
	Blue/Mem		Blue		4
	Violet/Status		Smart		5
	Menu		Menu		6
	Exit		Exit		7
	Up		Up		8
	Down		Down		9
	Right		Right		0
	Left		Left		AV
	OK		Ok		
	Vol+		Vol +		
	Vol-		Vol -		
	Mute		Mute		
	PR+		Ch +		

