










































Original	Recharge
 Power	 Power
 TV/DTV	 Smart
 Source	 AV
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 Recall	 Pre Ch
 Info	 Info
 FAV	 Shift + Pre Ch
 Picture	 Shift + Format

Original	Recharge
 Sound	 Shift + Dual
 Vol+	 Vol +
 Vol-	 Vol -
 Mute	 Mute
 CH+	 Ch +
 CH-	 Ch -
 Menu	 Menu
 EPG	 Guide
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 OK	 Ok
 I/II	 Dual
 Still	 Format
 Zoom	 Eject
 Exit	 Exit



