Original		Replacement	
	Power		Power
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
AD	AD	TITLE SOUND	Sound / Title
0	0	0	0
	Source	RDS AV INPUT	AV / Input / RDS
+	Vol +	+ VOL	Vol +
CONTENT MENU ATV DTV	ATV/DTV/Content Menu	LIST SMART	Smart / List
P	P+	+ CH PAGE	CH+ / Page+
	Vol -	VOL −	Vol -

Original		Replacement	
	Mute	DIMMER MUTE	Mute / Dimmer
P	P-	CH PAGE −	CH- / Page-
TOP MENU GUIDE	Guide/Top	TOP MENU D.MENU	D.Menu / Top
TOP MENU GUIDE	Guide/Top	-/-- GUIDE EPG	Guide / EPG / -/--
RETURN EXIT	Exit/Return	RETURN BACK	Back / Return
RETURN EXIT	Exit/Return	CLEAR EXIT CANCEL	Exit / Cancel / Clear
	Up		Up
	Left		Left
OK	OK	OK	OK
	Right		Right
DVD MENU MENU	Menu/DVD	HOME MENU	Menu / Home
	Down		Down
SET UP TV/FAV RADIO	Tv/FAV/Radio/Set	PROGRAM TV/ RADIO	TV/Radio /
	Red	NETFLIX SEARCH	Red / Netflix / Search
	Green	APP REPEAT	Green / APP / Repeat
	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat
	Blue	Prime Video RANDOM	Blue / Prime Video / Random

Original		Replacement		Original	Replacement
	[<>]	FORMAT PICTURE	Picture / Format		
	←[/]→	MEDIA DISPLAY	Display / Media		
	[i +] / [≡i]	ANGLE INFO	Info / Angle		
AUDIO TEXT	Text	GOTO TEXT	Text / Goto		
AUDIO TEXT	Audio	LANG I/II AUDIO	Audio / Lang I/II		
SUBTITLE	Subtitle	EQ SUBTITLE	Subtitle / EQ		
SUBTITLE	Eject	SURROUND	Eject / Surround		
CD I/II	O) I / I I	SHIFT + LANG I/II AUDIO	Shift + Audio / Lang I/II		
CD I/II	Stop	HOLD	Stop / Hold		
	Play/ [≡o]	SLOW	Play / Slow		
	I I / I I >/ [▼]	STEP-FREEZE	Pause / Step / Freeze		
	I <</ [≡?]	PRESET-	I << / Preset-		
	<</ [≡+]	TUNE-	<< / Tune-		
	>>/ [≡♦]	TUNE+	>> / Tune+		
	>>I / [O] / [≡X]	PRESET+	>>I / Preset+		

Original	Replacement	Original	Replacement
Power	Power	Exit / Return	Exit / Cancel / Clear
1	1	Exit / Return	Back / Return
2	2	Up	Up
3	3	Left	Left
4	4	OK	OK
5	5	Right	Right
6	6	Menu/ DVD	Menu / Home
7	7	Down	Down
8	8	Tv/ FAV/ Radio/ Set	TV/ Radio /
9	9	Tv/ FAV/ Radio/ Set	Setup / OPT /
0	0	[<>]	Picture / Format
Source	AV / Input / RDS	←[/]→	Display / Media
Vol +	Vol +	[i+]/[≡i]	Info / Angle
Vol -	Vol -	Text	Text / Goto
Mute	Mute / Dimmer	Audio	Audio / Lang I/II
Guide/ Top	Guide / EPG / -/--	Subtitle	Subtitle / EQ
Guide/ Top	D. Menu / Top	Eject	Eject / Surround

Menu Menu

Original		Replacement		Original	Replacement
	O) I / I I	SHIFT + LANG I/II AUDIO	Shift + Audio / Lang I/II		
	Stop	HOLD	Stop / Hold		
	Play/ [≡o]	SLOW	Play / Slow		
	I I / I I >/ [▼]	STEP-FREEZE	Pause / Step / Freeze		
	I <</ [≡?]	PRESET-	I << / Preset-		
	<</ [≡+]	TUNE-	<< / Tune-		
	>>/ [≡♦]	TUNE+	>> / Tune+		
	>>I / [O] / [≡X]	PRESET+	>>I / Preset+		

Original		Replacement	
	Power		Power
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	AD		Sound / Title
	0		0
	Source		AV / Input / RDS
	Vol +		Vol +
	ATV/ DTV/ Content Menu		Setup / OPT /
	P+		CH+ / Page+
	Vol -		Vol -

Original		Replacement	
	Mute		Mute / Dimmer
	P-		CH- / Page-
	Guide/Top		Guide / EPG / -/--
	Guide/Top		D.Menu / Top
	Exit/Return		Exit / Cancel / Clear
	Exit/Return		Back / Return
	Up		Up
	Left		Left
	OK		OK
	Right		Right
	Menu/DVD		Menu / Home
	Down		Down
	Tv/FAV/Radio/Set		TV/Radio /
	Red		Red / Netflix / Search
	Green		Green / APP / Repeat
	Yellow		Yellow / YouTube / Repeat
	Blue		Blue / Prime Video / Random

Original		Replacement		Original	Replacement
	[<>]	FORMAT PICTURE	Picture / Format		
	←[/]→	MEDIA DISPLAY	Display / Media		
	[i +] / [≡i]	ANGLE INFO	Info / Angle		
AUDIO TEXT	Text	GOTO TEXT	Text / Goto		
AUDIO TEXT	Audio	LANG I/II AUDIO	Audio / Lang I/II		
SUBTITLE	Subtitle	EQ SUBTITLE	Subtitle / EQ		
SUBTITLE	Eject	SURROUND	Eject / Surround		
CD I/II	O) I / I I	SHIFT + LANG I/II AUDIO	Shift + Audio / Lang I/II		
CD I/II	Stop	HOLD	Stop / Hold		
	Play/ [≡o]	SLOW	Play / Slow		
	I I / I I >/ [▼]	STEP-FREEZE	Pause / Step / Freeze		
	I <</ [≡?]	PRESET-	I << / Preset-		
	<</ [≡+]	TUNE-	<< / Tune-		
	>>/ [≡♦]	TUNE+	>> / Tune+		
	>>I / [O] / [≡X]	PRESET+	>>I / Preset+		