Original		Replacement	
	Power		Power
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
FAV	FAV	FAV PRE-CH	Pre Ch
TXT	TXT	REPEAT TEXT	Text
	Red	A	Red
	Green	B	Green
	Yellow	C	Yellow
	Blue	D	Blue

Original		Replacement	
GUIDE	Guide	-/-- GUIDE	Guide
?	?	SOUND DUAL	Dual
EXIT	Exit	CLEAR EXIT	Exit
MENU	Menu	TOP MENU MENU	Menu
BACK	Back	RETURN BACK	Back
TOOLS	Tools	SETTINGS OPT	Options
@	@	APP MEDIA	Media
	Up		Up
	Down		Down
	Right		Right
	Left		Left
OK	OK	OK	Ok
+ VOL	Vol +	+ VOL	Vol +
VOL -	Vol -	VOL -	Vol -
	Mute	MUTE	Mute
	Source	TIMER AV	AV
+ P	P+	+ CH	Ch +

Original		Replacement		Original	Replacement
P-		Ch -			
I <		I <<			
>I		>>I			
<<		<<			
>>		>>			
Rec		Rec			
Play		Play			
Pause		Pause			
Stop		Stop			
3D		3D			
OQ		Format			
[...]..		Subt			
Netflix		Smart			
My Media		Shift + Media			