

Original		Replacement
RECEIVER	Power Receiver	Power
5 EFFE	Effect-	8
6 EFFECT +	Effect+	9
MASTER VOLUME +	Master	+ VOL
–	Master Volume-	VOL –
TUNE ▲ +	Up/Tune+	Up
TUNE ▼ –	Down/Tune-	Down
ENTER	Enter	OK
ST+ ▶	Right/ST+	Right
ST– ◀	Left/ST-	Left
DOLBY DTS	Dolby	SOUND DUAL
DSP	DSP	DISPLAY INFO
TEST TONE	Test Tone	AD SUBT
CH SELECT	CH Select	A
LOUDNESS	Loudness	B
FUNCTION	Function	HOME SMART
MUTING	Muting	MUTE

Original		Replacement
FL DIMMER	FL Dimmer	C
LEVEL +	CH Level +	+ CH
CH LEVEL –	CH Level -	CH –
DVD	DVD	1
TV	TV	2
VCR	VCR	3
CD-R	CD-R	4
TUN	TUN	5
1 MIDNIGHT	Midnight	SETTINGS OPT
2 6.1/7.1	5.1CH	SEARCH TV/R
3 ATT	ATT	D
SIGNAL SELECT	Signal Select	APP MEDIA
TV POWER	Power TV	SHIFT + Power
1 MIDNIGHT	1 Tv	SHIFT + 1 — Shift + 1
2 6.1/7.1	2 Tv	SHIFT + 2 — Shift + 2
3 ATT	3 Tv	SHIFT + 3 — Shift + 3
4	4 Tv	SHIFT + 4 — Shift + 4



Original	Replacement
5 Tv	Shift + 5
6 Tv	Shift + 6
7 Tv	Shift + 7
8 Tv	Shift + 8
9 Tv	Shift + 9
0 Tv	Shift + 0
+10 Tv	Shift + Guide
Menu Tv	Shift + Menu
Tv Func	Shift + Smart
Tv Vol +	Shift + Vol +
Tv Vol -	Shift + Vol -
Channel + Tv	Shift + Ch +
Channel - Tv	Shift + Ch -
Up Tv	Shift + Up
Enter Tv	Shift + Ok
Down Tv	Shift + Down
Right Tv	Shift + Right

Original	Replacement
Left Tv	Shift + Left
Pause Tv	Shift + Pause
Play/D.Access Tv	Shift + Play
Stop/MPX Tv	Shift + Stop
>>I/RF ATT Tv	Shift + >>I
<</Band Tv	Shift + <<
Dolby Tv	Shift + Dual
>>/Class Tv	Shift + >>
Disc Tv	Shift + Back
DSP Tv	Shift + Info
I<</Display Tv	Shift + I<<
Test Tone Tv	Shift + Subt
Rec Tv	Shift + Rec



Original		Replacement	
SOURCE	Power DVD		Power
1	1 DVD	1	1
2	2 DVD	2	2
3	3 DVD	3	3
4	4 DVD	4	4
5	5 DVD	5	5
6	6 DVD	6	6
7	7 DVD	7	7
8	8 DVD	8	8
9	9 DVD	9	9
0	0 DVD	0	0
+10	+10 DVD	GUIDE	Guide
DISC	Disc DVD	RETURN BACK	Back
MENU	Menu DVD	TOP MENU MENU	Menu
MASTER VOLUME +	Master	VOL +	Vol +
MASTER VOLUME -	Master volume-	VOL -	Vol -
MUTING	Muting	MUTE	Mute

Original		Replacement	
CHANNEL +	Channel + DVD	CH +	Ch +
CHANNEL -	Channel - DVD	CH -	Ch -
TUNE ▲ +	Up DVD		Up
TUNE ▼ -	Down DVD		Down
ST+ ▶	Right DVD		Right
ST- ◀	Left DVD		Left
ENTER	Enter DVD	OK	Ok
	Pause DVD		Pause
	Rec DVD	REC MODE	Rec
D.ACCESS ▶	Play DVD	PLAY MODE ▶	Play
BAND ◀◀	<< DVD		<<
CLASS ▶▶	>> DVD		>>
MPX ■	Stop DVD		Stop
RF ATT ▶▶I	>>I DVD		>>I
DISPLAY I◀◀	I << DVD		I <<
DOLBY DIGITAL	Dolby DVD	SOUND DUAL	Dual
DSP	DSP DVD	DISPLAY INFO	Info



Original	Replacement
Test Tone DVD	Subt
Signal Effect DV	TV/R
Power VCR	Shift + Power
1 VCR	Shift + 1
2 VCR	Shift + 2
3 VCR	Shift + 3
4 VCR	Shift + 4
5 VCR	Shift + 5
6 VCR	Shift + 6
7 VCR	Shift + 7
8 VCR	Shift + 8
9 VCR	Shift + 9
0 VCR	Shift + 0
Disc VCR	Shift + Back
Channel + VCR	Shift + Ch +
Channel - VCR	Shift + Ch -
Up VCR	Shift + Up

Original	Replacement
Down VCR	Shift + Down
Right VCR	Shift + Right
Left VCR	Shift + Left
Enter VCR	Shift + Ok
Pause VCR	Shift + Pause
Play VCR	Shift + Play
Stop VCR	Shift + Stop
<< VCR	Shift + <<
>>I VCR	Shift + >>I
>> VCR	Shift + >>
I << VCR	Shift + I <<
Rec VCR	Shift + Rec



Original		Replacement	
SOURCE	Power CD		Power
1	1 CD	1	1
2	2 CD	2	2
3	3 CD	3	3
4	4 CD	4	4
5	5 CD	5	5
6	6 CD	6	6
7	7 CD	7	7
8	8 CD	8	8
9	9 CD	9	9
0	0 CD	0	0
+10	+10 CD	GUIDE	Guide
DISC	Disc CD	RETURN BACK	Back
MASTER VOLUME +	Master	VOL +	Vol +
MASTER VOLUME -	Master Volume-	VOL -	Vol -
MUTING	Muting	MUTE	Mute
CHANNEL +	Channel + CD	CH +	Ch +

Original		Replacement	
CHANNEL -	Channel - CD	CH -	Ch -
TUNE ▲ +	Up CD	▲	Up
TUNE ▼ -	Down CD	▼	Down
ST+ ▶	Right CD	▶	Right
ST- ◀	Left CD	◀	Left
ENTER	Enter CD	OK	Ok
❚❚	Pause CD	❚❚	Pause
D.ACCESS ▶	Play CD	PLAY MODE ▶	Play
BAND ◀◀	<< CD	◀◀	<<
CLASS ▶▶	>> CD	▶▶	>>
MPX ■	Stop CD	■	Stop
DISPLAY ⏮	I<< CD	⏮	I<<
RF ATT ⏭	>>I CD	⏭	>>I
SOURCE	Power TVC	SHIFT +	Shift + Power
1 MIDNIGHT	1 TVC	SHIFT + 1	Shift + 1
2	2 TVC	SHIFT + 2	Shift + 2
3 ATT	3 TVC	SHIFT + 3	Shift + 3



Original		Replacement		Original		Replacement	
4	4 TVC	SHIFT + 4	Shift + 4	D.ACCESS	Play TVC	SHIFT + PLAY MODE	Shift + Play
5	5 TVC	SHIFT + 5	Shift + 5	MPX	Stop TVC	SHIFT + ■	Shift + Stop
6	6 TVC	SHIFT + 6	Shift + 6	BAND	<< TVC	SHIFT + ⏪	Shift + <<
7	7 TVC	SHIFT + 7	Shift + 7	CLASS	>> TVC	SHIFT + ⏩	Shift + >>
8	8 TVC	SHIFT + 8	Shift + 8	RF ATT	>>I TVC	SHIFT + ⏭	Shift + >>I
9	9 TVC	SHIFT + 9	Shift + 9	DISPLAY	I << TVC	SHIFT + ⏮	Shift + I <<
0	0 TVC	SHIFT + 0	Shift + 0				
+10	+10 TVC	SHIFT + GUIDE	Shift + Guide				
DISC	Disc TVC	SHIFT + RETURN BACK	Shift + Back				
MENU	Menu TVC	SHIFT + TOP MENU MENU	Shift + Menu				
TUNE ▲+	Up TVC	SHIFT + ▲	Shift + Up				
TUNE ▼-	Down TVC	SHIFT + ▼	Shift + Down				
ST+ ▶	Right TVC	SHIFT + ▶	Shift + Right				
ST- ◀	Left TVC	SHIFT + ◀	Shift + Left				
ENTER	Enter TVC	SHIFT + OK	Shift + Ok				
⏸	Pause TVC	SHIFT + ⏸	Shift + Pause				
●	Rec TVC	SHIFT + REC MODE	Shift + Rec				



Original		Replacement	
SOURCE	Power TUN		Power
1	1 TUN	1	1
2	2 TUN	2	2
3	3 TUN	3	3
4	4 TUN	4	4
5	5 TUN	5	5
6	6 TUN	6	6
7	7 TUN	7	7
8	8 TUN	8	8
9	9 TUN	9	9
0	0 TUN	0	0
MASTER VOLUME +	Master	VOL +	Vol +
MASTER VOLUME -	Master volume-	VOL -	Vol -
MUTING	Muting	MUTE	Mute
TUNE+	TUNE+ TUN		Up
TUNE-	TUNE- TUN		Down
ST+	ST+ TUN		Right

Original		Replacement	
ST-	ST- TUN		Left
D.ACCESS	D.Access TUN	PLAY MODE	Play
BAND	Band TUN		<<
CLASS	Class TUN		>>
MPX	MPX TUN		Stop
DISPLAY	Display TUN		I <<
RF ATT	RF ATT TUN		>>I
SOURCE	Power CDR	SHIFT +	Shift + Power
1	1 CDR	SHIFT + 1	Shift + 1
2	2 CDR	SHIFT + 2	Shift + 2
3	3 CDR	SHIFT + 3	Shift + 3
4	4 CDR	SHIFT + 4	Shift + 4
5	5 CDR	SHIFT + 5	Shift + 5
6	6 CDR	SHIFT + 6	Shift + 6
7	7 CDR	SHIFT + 7	Shift + 7
8	8 CDR	SHIFT + 8	Shift + 8
9	9 CDR	SHIFT + 9	Shift + 9



Original		Replacement		Original	Replacement
0	0 CDR	SHIFT + 0	Shift + 0		
+10	+10 CDR	SHIFT + GUIDE	Shift + Guide		
CHANNEL +	Channel + CDR	SHIFT + CH +	Shift + Ch +		
CHANNEL -	Channel - CDR	SHIFT + CH -	Shift + Ch -		
TUNE ▲ +	Up CDR	SHIFT + ▲	Shift + Up		
TUNE ▼ -	Down CDR	SHIFT + ▼	Shift + Down		
ST+ ▶	Right CDR	SHIFT + ▶	Shift + Right		
ST- ◀	Left CDR	SHIFT + ◀	Shift + Left		
ENTER	Enter CDR	SHIFT + OK	Shift + Ok		
❚❚	Pause CDR	SHIFT + ❚❚	Shift + Pause		
D.ACCESS ▶	Play CDR	SHIFT + PLAY MODE ▶	Shift + Play		
MPX ■	Stop CDR	SHIFT + ■	Shift + Stop		
BAND ◀◀	<< CDR	SHIFT + ≪	Shift + <<		
●	Rec CDR	SHIFT + REC MODE ●	Shift + Rec		
DISPLAY ⏮	I<< CDR	SHIFT + ⏮	Shift + I<<		
RF ATT ⏭	>>I CDR	SHIFT + ⏭	Shift + >>I		
CLASS ▶▶	>> CDR	SHIFT + ≫	Shift + >>		