Original		Replacement		Original		Replacement	
STANDBY	Standby	SHIFT +	Shift + Power	2	System Memory	SHIFT + DVD 2	Shift + 2
POWER I	Power		Power	3	System Memory	SHIFT + CD-STB 3	Shift + 3
MULTI	Multi	-/-- GUIDE EPG	Guide / EPG / -/--	4	System Memory	SHIFT + VIDEO 4	Shift + 4
V-AUX	V-AUX	AUX-HDD 7	7	TITLE BAND	Title	TITLE SOUND	Sound / Title
PHONO	Phono	SHIFT + TITLE SOUND	Shift + Sound / Title	MENU SRCH MODE	Menu	HOME MENU	Menu / Home
DOCK	Dock	SIZE ZOOM	Zoom / Size	VOLUME +	Vol +	+ VOL	Vol +
BD HD DVD	BD/HD DVD	SHIFT + TAPE 5	Shift + 5		Up		Up
DVD	DVD	DVD 2	2		Left		Left
CD	CD	CD-STB 3	3	ENTER	Enter	OK	OK
MD CD-R	MD/CD-R	GOTO TEXT	Text / Goto	A-E	Right		Right
CBL SAT	CBL/SAT	SHIFT + PROGRAM TV/RADIO	Shift + TV/Radio / Program		Down		Down
TV	TV	PROGRAM TV/RADIO	TV/Radio /	–	Vol -	VOL –	Vol -
DVR	DVR	TOP MENU D.MENU	D.Menu / Top	RETURN MEMORY	Return	RETURN BACK	Back / Return
VCR	VCR	VIDEO 4	4	PARAMETER DISPLAY	Display	MEDIA DISPLAY	Display / Media
TUNER	Tuner	TUNER 6	6	MUTE	Mute	DIMMER MUTE	Mute / Dimmer
USB	USB	USB 8	8	CLASSICAL 1	1/Classical	TV 1	1
1	System Memory	SHIFT + TV 1	Shift + 1	LIVE/CLUB 2	2/Live Club	SHIFT + MEDIA DISPLAY	Shift + Display / Media

Original		Replacement		Original	Replacement
ENTERTAIN 3	3/ Entertain	LIST SMART	Smart / List		
MOVIE 4	4/ Movie	SHIFT + LIST SMART	Shift + Smart / List		
STEREO 5	5/ Stereo	TAPE 5	5		
ENHANCER 6	6/ Enhancer	SHIFT + TUNER 6	Shift + 6		
SUR. DECODE 7	7/ Sur. Decode	SHIFT + AUX - HDD 7	Shift + 7		
STRAIGHT 8	8/ Straight	SHIFT + USB 8	Shift + 8		
9	9	BLUETOOTH 9	9		
0	0	HDMI - SAT 0	0		
EXTD SUR. +10	+10/ EXTD Sur.	PC FAV MARKER	Fav / Marker / PC		
PURE DIRECT ENT	ENT/ Pure Direct	SHIFT + OK	Shift + OK		
INFO +	Info	ANGLE INFO	Info / Angle		
LEVEL +	Level	OPT-TOOLS SETUP	Setup / OPT /		
SLEEP MUTE	Sleep	TIMER SLEEP	Sleep / Timer		
AUDIO SEL AUDIO	Audio/ Audio Se	LANG I/II AUDIO	Audio / Lang I/II		
3D DSP	3D DSP	FORMAT PICTURE	Picture / Format		

Original		Replacement		Original		Replacement	
POWER	Power		Power		<<	TUNE-	<< / Tune-
TITLE BAND	Title	TITLE SOUND	Sound / Title	EON	>>	TUNE+	>> / Tune+
MENU SRCH MODE	Menu	HOME MENU	Menu / Home	MODE – PTY	I <<	PRESET-	I << / Preset-
VOLUME +	Vol +	+ VOL	Vol +	SEEK – START	>>I	PRESET+	>>I / Preset+
	Up		Up	CLASSICAL 1	1	TV 1	1
	Left		Left	LIVE/CLUB 2	2	DVD 2	2
ENTER	Enter	OK	OK	ENTERTAIN 3	3	CD-STB 3	3
A-E	Right		Right	MOVIE 4	4	VIDEO 4	4
	Down		Down	STEREO 5	5	TAPE 5	5
–	Vol -	VOL –	Vol -	ENHANCER 6	6	TUNER 6	6
RETURN MEMORY	Return	RETURN BACK	Back / Return	SUR. DECODE 7	7	AUX-HDD 7	7
PARAMETER DISPLAY	Display	MEDIA DISPLAY	Display / Media	STRAIGHT 8	8	USB 8	8
MUTE	Mute	DIMMER MUTE	Mute / Dimmer	9	9	BLUETOOTH 9	9
REC	Rec	REC MODE	Rec / Rec Mode	0	0	HDMI-BAT 0	0
	Pause	STEP-FREEZE	Pause / Step / Freeze	EXTD SUR. +10	+10	-/-- GUIDE EPG	Guide / EPG / -/--
	Play	SLOW	Play / Slow	PURE DIRECT ENT	ENT	SHIFT + OK	Shift + OK
	Stop	HOLD	Stop / Hold	AUDIO SEL AUDIO	Audio	LANG I/II AUDIO	Audio / Lang I/II

Original		Replacement	
POWER	Power		Power
TITLE BAND	Band	TOP MENU D.MENU	D. Menu / Top
MENU SRCH MODE	SRCH Mode	OPT-TOOLS SETUP	Setup / OPT /
VOLUME +	Vol +	+ VOL	Vol +
	UP Preset / CH+		Up
	Left		Left
ENTER	Enter	OK	OK
A-E	Right / A-E		Right
	Down		Down
–	Vol -	VOL –	Vol -
RETURN MEMORY	Memory	LIST SMART	Smart / List
PARAMETER DISPLAY	Parameter	HOME MENU	Menu / Home
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
REC	Rec	REC MODE	Rec / Rec Mode
	Pause	STEP-FREEZE	Pause / Step / Freeze
	Play	SLOW	Play / Slow
	Stop	HOLD	Stop / Hold

Original		Replacement	
	<<	TUNE-	<< / Tune-
EON	>>	TUNE+	>> / Tune+
MODE – PTY	I <<	PRESET-	I << / Preset-
SEEK – START	>>I	PRESET+	>>I / Preset+
CLASSICAL 1	1	TV 1	1
LIVE/CLUB 2	2	DVD 2	2
ENTERTAIN 3	3	CD-STB 3	3
MOVIE 4	4	VIDEO 4	4
STEREO 5	5	TAPE 5	5
ENHANCER 6	6	TUNER 6	6
SUR. DECODE 7	7	AUX-HDD 7	7
STRAIGHT 8	8	USB 8	8
9	9	BLUETOOTH 9	9
0	0	HDMI-BAT 0	0
EXTD SUR. +10	+10	-/-- GUIDE EPG	Guide / EPG / -/--
PURE DIRECT ENT	ENT	SHIFT + OK	Shift + OK
AUDIO SEL AUDIO	Audio	LANG I/II AUDIO	Audio / Lang I/II

Original		Replacement	
POWER	Power		Power
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
	Play	SLOW	Play / Slow
	Pause	STEP-FREEZE	Pause / Step / Freeze
	Stop	HOLD	Stop / Hold
REC	Rec	REC MODE	Rec / Rec Mode
	<<	TUNE-	<< / Tune-
	>>	TUNE+	>> / Tune+
	I<<	PRESET-	I<< / Preset-
	>>I	PRESET+	>>I / Preset+
TITLE	Title	TITLE SOUND	Sound / Title
AUDIO SEL AUDIO	Audio	LANG I/II AUDIO	Audio / Lang I/II
MENU	Menu	HOME MENU	Menu / Home
	Up		Up
	Left		Left
ENTER	Enter	OK	OK
	Right		Right

Original		Replacement	
	Down		Down
RETURN MEMORY	Return	RETURN BACK	Back / Return
VOLUME +	Vol +	+ VOL	Vol +
PURE DIRECT ENT	ENT	LIST SMART	Smart / List
	Vol -	VOL –	Vol -
PARAMETER DISPLAY	Display	MEDIA DISPLAY	Display / Media
CLASSICAL 1	1	TV 1	1
LIVE/CLUB 2	2	DVD 2	2
ENTERTAIN 3	3	CD-STB 3	3
MOVIE 4	4	VIDEO 4	4
STEREO 5	5	TAPE 5	5
ENHANCER 6	6	TUNER 6	6
SUR. DECODE 7	7	AUX-HDD 7	7
STRAIGHT 8	8	USB 8	8
9	9	BLUETOOTH 9	9
EXTD SUR. +10	+10	-/-- GUIDE EPG	Guide / EPG / -/--
0	0	HDMI-SAT 0	0

Original		Replacement	
EXTD SUR. +10	+10 Multi	PC FAV MARKER	Fav / Marker / PC
STANDBY	Power Multi	SHIFT +	Shift + Power
	Play Multi	SHIFT + SLOW	Shift + Play /
	Pause Multi	SHIFT + STEP-FREEZE	Shift + Pause / Step /
	Stop Multi	SHIFT + HOLD	Shift + Stop /
REC	Rec Multi	SHIFT + REC MODE	Shift + Rec / Rec Mode
	<< Multi	SHIFT + TUNE-	Shift + << /
EON	>> Multi	SHIFT + TUNE+	Shift + >> /
MODE – PTY	I<< Multi	SHIFT + PRESET-	Shift + I<< / Preset-
SEEK – START	>>I Multi	SHIFT + PRESET+	Shift + >>I / Preset+
TITLE BAND	Title Multi	SHIFT + TITLE SOUND	Shift + Sound / Title
AUDIO SEL AUDIO	Audio Multi	SHIFT + LANG I/II AUDIO	Shift + Audio / Lang I/II
MENU SRCH MODE	Menu Multi	SHIFT + HOME MENU	Shift + Menu /
	Up Multi	SHIFT +	Shift + Up
	Left Multi	SHIFT +	Shift + Left
ENTER	Enter Multi	SHIFT + OK	Shift + OK
A-E	Right Multi	SHIFT +	Shift + Right

Original		Replacement	
	Down Multi	SHIFT +	Shift + Down
RETURN MEMORY	Return Multi	SHIFT + RETURN BACK	Shift + Back / Return
PURE DIRECT ENT	ENT Multi	SHIFT + LIST SMART	Shift + Smart / List
PARAMETER DISPLAY	Display Multi	SHIFT + MEDIA DISPLAY	Shift + Display / Media
CLASSICAL 1	1 Multi	SHIFT + TV 1	Shift + 1
LIVE/CLUB 2	2 Multi	SHIFT + DVD 2	Shift + 2
ENTERTAIN 3	3 Multi	SHIFT + CD-STB 3	Shift + 3
MOVIE 4	4 Multi	SHIFT + VIDEO 4	Shift + 4
STEREO 5	5 Multi	SHIFT + TAPE 5	Shift + 5
ENHANCER 6	6 Multi	SHIFT + TUNER 6	Shift + 6
SUR. DECODE 7	7 Multi	SHIFT + AUX-HDD 7	Shift + 7
STRAIGHT 8	8 Multi	SHIFT + USB 8	Shift + 8
9	9 Multi	SHIFT + BLUETOOTH 9	Shift + 9
0	0 Multi	SHIFT + HDMI - SAT 0	Shift + 0