Original		Replacement		Original		Replacement	
	Power		Power	+ P	P+	+ CH PAGE	CH+ / Page+
	Red	NETFLIX SEARCH	Red / Netflix / Search	V −	Vol -	VOL −	Vol -
	Green	APP REPEAT	Green / APP / Repeat		Mute	DIMMER MUTE	Mute / Dimmer
	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat	P −	P-	CH PAGE −	CH- / Page-
	Blue	Prime Video RANDOM	Blue / Prime Video / Random	1	1	TV 1	1
M	Menu	HOME MENU	Menu / Home	2	2	DVD 2	2
P<P	P<P	LIST SMART	Smart / List	3	3	CD - STB 3	3
	Up		Up	4	4	VIDEO 4	4
	Left		Left	5	5	TAPE 5	5
OK	Ok	OK	OK	6	6	TUNER 6	6
	Right		Right	7	7	AUX - HDD 7	7
	Down		Down	8	8	USB 8	8
AV	AV	RDS AV INPUT	AV / Input / RDS	9	9	BLUETOOTH 9	9
TV/	Tv/R	PROGRAM TV/ RADIO	TV/Radio /	PP	PP	RETURN BACK	Back / Return
INFO i	Info	ANGLE INFO	Info / Angle	0	0	HDMI - SAT 0	0
I-II	I-II	LANG I/II AUDIO	Audio / Lang I/II	-/-- EXIT	-/-- Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
+ V	Vol +	+ VOL	Vol +	-/-- EXIT	-/-- Exit	SHIFT + -/-- GUIDE EPG	Shift + Guide / EPG / -/--

Original		Replacement		Original	Replacement
	[≡] / Text	GOTO TEXT	Text / Goto		
	[≡o]	TUNE-	<< / Tune-		
	[≡+]	TUNE+	>> / Tune+		
	[≡x]	PRESET-	I<< / Preset-		
	[. ≡] / [*]	PRESET+	>>I / Preset+		
WIDE	[≡♦] / [+] / Wide	FORMAT PICTURE	Picture / Format		
PC	[≡?] / PC	PC FAV MARKER	Fav / Marker / PC		
GUIDE	[≡i] / Guide	-/-- GUIDE EPG	Guide / EPG / -/--		