Original	Replacement	Original	Replacement
Power	Power	Scan >>	>>
DVD	Text	I << Skip	I <<
HDD	D. Menu	Skip >>I	>>I
Open/Close	Eject	Pause/Step	Pause
1	1	Play	Play
2	2	Stop	Stop
3	3	Menu/List	Menu
4	4	Home	Smart
5	5	Return	Back
6	6	Display	Info
7	7	Up	Up
8	8	Down	Down
9	9	Right	Right
0	0	Left	Left
AV/Input	AV	Enter	Ok
Rec	Rec	PR+	Ch +
<< Scan	<<	PR-	Ch -

Original		Replacement	
PR LIST	PR List	DISC NAV LIST	List
EPG	EPG	-/-- GUIDE	Guide
FAV	Red/ FAV	A	Red
REPEAT	Green/ Repeat	B	Green
SUBTITLE	Yellow/ Subtitl	C	Yellow
TEXT	Blue/ Text	D	Blue
AUDIO	O)) / Audio	SOUND DUAL	Dual
TITLE	Title	AD SUBT	Subt
MARKER	Marker	ECO 3D	3D
CLEAR	Clear	CLEAR EXIT	Exit
TIMESHIFT	Timeshift	PICTURE FORMAT	Format
TV/DVD	Tv/ DVD	SEARCH TV/R	TV/ R
TV POWER	Power Tv	SHIFT +	Shift + Power
AV/INPUT	AV/ Input Tv	SHIFT + TIMER AV	Shift + AV
PR/CH	PR/ CH+ Tv	SHIFT + CH +	Shift + Ch +
	PR/ CH- Tv	SHIFT + CH -	Shift + Ch -
VOL	Vol + Tv	+ VOL	Vol +

Original		Replacement	
	Vol - Tv	VOL -	Vol -