Mandis shop

VEQ0735

Original		Replacement	
VTR	VTR	LIST SMART	Smart / List
VTR	VTR	VIDEO 4	4
VTR/TV	VTR/TV	MEDIA DISPLAY	Display / Media
VTR/TV	VTR/TV	TV 1	1
CLOCK/COUNTER	Clock/Counter	OPT-TOOLS SETUP	Setup / OPT /
	Down	CH PAGE −	CH- / Page-
	Down		Down
	Up	CH PAGE +	CH+ / Page+
	Up		Up
	Rec	REC MODE	Rec / Rec Mode
PAUSE/STILL	Pause/Still	STEP-FREEZE	Pause / Step / Freeze
STOP	Stop	HOLD	Stop / Hold
STILL ADV	Still Adv	OK	OK
REW/	Rew	TUNE-	<< / Tune-
PLAY	Play	SLOW	Play / Slow
/FF	FF	TUNE+	>> / Tune+
SLOW	Slow	SHIFT + SLOW	Shift + Play / Slow

Original		Replacement	
SLOW	Slow	PRESET+	>>I / Preset+

https://al-remote-controls.nl/en/1882-105-replacement-remote-control-for-VEQ0735.htm