Original		Replacement	
POWER	Power		Power
DISPLAY	Display	MEDIA DISPLAY	Display / Media
DIMMER	Dimmer	DIMMER MUTE	Mute / Dimmer
OPEN/ CLOSE	Open/Close	SURROUND	Eject / Surround
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
SEARCH	Search	NETFLIX SEARCH	Red / Netflix / Search
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
+10	+10	-/-- GUIDE EPG	Guide / EPG / -/--
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
0	0	HDMI - SAT 0	0
MENU	Menu	HOME MENU	Menu / Home

Original		Replacement	
	Up		Up
TOP MENU	Top Menu	TOP MENU D.MENU	D.Menu / Top
	Left		Left
ENTER	Enter	OK	OK
	Right		Right
RETURN	Return	RETURN BACK	Back / Return
	Down		Down
SETUP	Setup	OPT-TOOLS SETUP	Setup / OPT /
AUDIO	Audio	LANG I/II AUDIO	Audio / Lang I/II
ANGLE	Angle	ANGLE INFO	Info / Angle
SUBTITLE	Subtitle	EQ SUBTITLE	Subtitle / EQ
SUBTITLE ON/OFF	Subtitle On/Of	PROGRAM TV/ RADIO	TV/Radio /
STOP	Stop	HOLD	Stop / Hold
PLAY	Play	SLOW	Play / Slow
PAUSE/STEP	Pause/Step	STEP - FREEZE	Pause / Step / Freeze
FR	<</FR	TUNE-	<< / Tune-
FF	>>/FF	TUNE+	>> / Tune+

Original		Replacement		Original	Replacement
DOWN	I <</ Down	PRESET-	I << / Preset-		
UP	>>I / Up	PRESET+	>>I / Preset+		
REPEAT	Repeat	APP REPEAT	Green / APP / Repeat		
A-B	A-B	YouTube REPEAT A-B	Yellow / YouTube / Repeat		
SLOW	<I Slow	CH PAGE	CH- / Page-		
SLOW	Slow I>	CH PAGE	CH+ / Page+		
MEMORY	Memory	GOTO TEXT	Text / Goto		
CLEAR	Clear	CLEAR EXIT CANCEL	Exit / Cancel / Clear		
RANDOM	Random	Prime Video RANDOM	Blue / Prime Video / Random		
ZOOM	Zoom	SIZE ZOOM	Zoom / Size		