Original		Replacement	
VCR	Power VCR		Power
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	Play	PLAY MODE	Play
	Stop		Stop
	>>		>>
	<<		<<
PAUSE/SLOW	Pause/Slow		Pause
REC/OTR	Rec/OTR	REC MODE	Rec
DISPLAY	Display	DISPLAY INFO	Info
ZERO STOP	Zero Stop	HOME SMART	Smart
JOG/SHUTTLE	Jog/Shuttle Or	APP MEDIA	Media
IND	I<< Index		I<<
DEX	>>I Index		>>I
VCR TRACKING/V-LOCK	Tracking/V-Lock+	CH +	Ch +

Original		Replacement	
TRACKING/V-LOCK	Tracking/V-Lock-	CH −	Ch -
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
T SAT 0	0	0	0
-/--	-/--	-/-- GUIDE	Guide
INPUT SELECT	Input Select	TIMER AV	AV
+	Vol +	+ VOL	Vol +
−	Vol -	VOL −	Vol -
OSD	OSD	RETURN BACK	Back
AUDIO OUT	Audio Out	SOUND DUAL	Dual

Original		Replacement	
TV/AV	Tv/AV	FAV PRE-CH	Pre Ch
TV	TV CH+	SHIFT + CH +	Shift + Ch +
	TV CH-	SHIFT + CH -	Shift + Ch -
TV	Power Tv	SHIFT +	Shift + Power
	<< Wheel	SHIFT +	Shift + Left
	Wheel >>	SHIFT +	Shift + Right
	Central Wheel >>	SHIFT +	Shift + Up
	<< Central Wheel	SHIFT +	Shift + Down
RESET	Reset	SEARCH TV/R	TV/R
MENU	Menu	TOP MENU MENU	Menu
EXIT	Exit	CLEAR EXIT	Exit
STORE	Store	ECO 3D	3D
PDC/VPS	PDC/VPS	D	Blue
SP/LP	SP/LP	PICTURE FORMAT	Format
TIMER REC	Timer Rec	A	Red
CHECK	Check	B	Green
TRANSMIT	Transmit	C	Yellow

Original		Replacement	
	Nothing 1	SHIFT + TIMER AV	Shift + AV
	Nothing 2	SHIFT + PICTURE FORMAT	Shift + Format
DIRECT TV REC	Direct Tv Rec	SETTINGS OPT	Options
AV LINK	AV Link	REPEAT TEXT	Text
JOG/SHUTTLE	Jog/Shuttle ▲	SHIFT + APP MEDIA	Shift + Media

Original		Replacement		Original		Replacement	
TV	Power		Power				
DIRECT TV REC	Direct Tv Rec	SETTINGS OPT	Options				
TV	CH+	CH +	Ch +				
	CH-	CH −	Ch -				
1	1	1	1				
2	2	2	2				
3	3	3	3				
4	4	4	4				
5	5	5	5				
6	6	6	6				
7	7	7	7				
8	8	8	8				
9	9	9	9				
T SAT 0	0	0	0				
	-/--	-/-- GUIDE	Guide				
	Vol +	VOL +	Vol +				
	Vol -	VOL −	Vol -				

Original		Replacement	
VCR	Power VCR		Power
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	Play	PLAY MODE	Play
	Stop		Stop
	>>		>>
	<<		<<
PAUSE/SLOW	Pause/Slow		Pause
REC/OTR	Rec/OTR	REC MODE	Rec
DISPLAY	Display	DISPLAY INFO	Info
RESET	Reset	SEARCH TV/R	TV/R
ZERO STOP	Zero Stop	HOME SMART	Smart
JOG/SHUTTLE	Jog/Shuttle Or	APP MEDIA	Media
JOG/SHUTTLE	Jog/Shuttle ▲	SHIFT + APP MEDIA	Shift + Media
IND	I<< Index		I<<

Original		Replacement	
DEX	Index >>I		>>I
VCR	Tracking/V.Lock+	CH +	Ch +
TRACKING/V.LOCK	Tracking/V.Lock-	CH -	Ch -
OSD	OSD	RETURN BACK	Back
AUDIO OUT	Audio Out	SOUND DUAL	Dual
INPUT SELECT	Input Select	TIMER AV	AV
TV/AV	Tv/AV	FAV PRE-CH	Pre Ch
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
T SAT	0	0	0

Original		Replacement	
-/--	-/--	GUIDE	Guide
Vol +	Vol +	VOL +	Vol +
Vol -	Vol -	VOL −	Vol -
TV	Tv CH+	SHIFT + CH +	Shift + Ch +
	Tv CH-	SHIFT + CH −	Shift + Ch -
DIRECT TV REC	Direct Tv Rec	SETTINGS OPT	Options
AV LINK	AV Link	REPEAT TEXT	Text
MENU	Menu	TOP MENU MENU	Menu
EXIT	Exit	CLEAR EXIT	Exit
STORE	Store	ECO 3D	3D
	Nothing 1	SHIFT + TIMER AV	Shift + AV
	Nothing 2	SHIFT + PICTURE FORMAT	Shift + Format
SP/LP	SP/LP	PICTURE FORMAT	Format
PDC/VPS	PDC/VPS	D	Blue
TRANSMIT	Transmit	C	Yellow
TV	Power Tv	SHIFT + ⏻	Shift + Power
TIMER REC	Timer Rec	A	Red

Original		Replacement	
CHECK	Check	B	Green