Original		Replacement	
	Power		Power
QUICK OSD	Quick OSD	APP MEDIA	Media
FL SELECT	FL Select	HOME SMART	Smart
OPEN/CLOSE	Open/Close	ZOOM	Eject
ADVANCED SURROUND	Advanced	SEARCH TV/R	TV/R
PICTURE MODE	Picture Mode	PICTURE FORMAT	Format
REPEAT	Repeat	REPEAT TEXT	Text
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0

Original		Replacement	
≥10	+10	-/-- GUIDE	Guide
CANCEL	Cancel	CLEAR EXIT	Exit
PLAY SPEED	Play Speed	A	Red
DIALOGUE ENHANCER	Dialogue	B	Green
MANUAL SKIP	Manual Skip	C	Yellow
QUICK REPLAY	Quick Replay	DISC NAV LIST	List
SKIP	I<< Skip	I<<	I<<
SKIP	Skip >>I	>>I	>>I
SLOW/SEARCH	<< Slow/Search	<<	<<
SLOW/SEARCH	Slow/Search >>	>>	>>
STOP	Stop		Stop
PAUSE	Pause		Pause
PLAY	Play	PLAY MODE	Play
TOP MENU DIRECT NAVIGATOR	Top Menu / Direct Navigator	SHIFT + TOP MENU MENU	Shift + Menu
MENU PLAY LIST	Menu / Play List	TOP MENU MENU	Menu
FUNCTIONS	Functions	E-MANUAL D.MENU	D. Menu
RETURN	Return	RETURN BACK	Back

Original	Replacement	Original	Replacement
Up	Up		
Down	Down		
Right	Right		
Left	Left		
OK	Ok		
Subtitle	Subt		
Audio	Dual		
Angle/Page	Blue		
Play Mode	Shift + Play		
Setup	Options		
Transfer Mode	AV		
Zoom	Shift + Eject		
DNR	3D		