Original	Replacement	Original	Replacement
Power	Power	Max	Smart / List
Open/Close	Eject / Surround	Vol -	Vol -
Up	Up	Vol +	Vol +
Preset/Album+	CH+ / Page+	1	1
I<<	I<< / Preset-	2	2
I<<	Left	3	3
Play/Pause	Play / Slow	4	4
Play/Pause	Pause / Step / Freeze	5	5
Play/Pause	OK	6	6
>>I	>>I / Preset+	7	7
>>I	Right	8	8
Preset/Album-	CH- / Page-	9	9
Down	Down	Prog/Clock Set	TV/Radio /
Mute	Mute / Dimmer	0	0
Disp	Display / Media	Repeat/Shuffle	Green / APP / Repeat
Stop	Stop / Hold	Repeat/Shuffle	Blue / Prime Video / Random
Menu	Menu / Home	Sleep/Timer	Sleep / Timer

Original		Replacement		Original	Replacement
DSC	DSC	OPT-TOOLS SETUP	Set up / OPT /		
DBB	DBB	TOP MENU D.MENU	D. Menu / Top		

Original	Replacement	Original	Replacement
Power	Power	Max	Smart / List
Open/Close	Eject / Surround	Vol -	Vol -
Up	Up	Vol +	Vol +
Preset/Album+	CH+ / Page+	1	1
I<<	I<< / Preset-	2	2
I<<	Left	3	3
Play/Pause	Play / Slow	4	4
Play/Pause	Pause / Step / Freeze	5	5
Play/Pause	OK	6	6
>>I	>>I / Preset+	7	7
>>I	Right	8	8
Preset/Album-	CH- / Page-	9	9
Down	Down	Prog/Clock Set	TV/Radio /
Disp	Display / Media	0	0
Mute	Mute / Dimmer	Repeat/Shuffle	Green / APP / Repeat
Stop	Stop / Hold	Repeat/Shuffle	Blue / Prime Video / Random
Menu	Menu / Home	Sleep/Timer	Sleep / Timer

Original		Replacement		Original	Replacement
DSC	DSC	OPT-TOOLS SETUP	Set up / OPT /		
DBB	DBB	TOP MENU D.MENU	D. Menu / Top		

Original	Replacement	Original	Replacement
Power	Power	Max	Smart / List
Open/Close	Eject / Surround	Vol -	Vol -
Up	Up	Vol +	Vol +
Preset/Album+	CH+ / Page+	1	1
I<<	I<< / Preset-	2	2
I<<	Left	3	3
Play/Pause	Play / Slow	4	4
Play/Pause	OK	5	5
Play/Pause	Pause / Step / Freeze	6	6
>>I	>>I / Preset+	7	7
>>I	Right	8	8
Preset/Album-	CH- / Page-	9	9
Down	Down	Prog/Clock Set	TV/Radio /
Disp	Display / Media	0	0
Mute	Mute / Dimmer	Repeat/Shuffle	Blue / Prime Video / Random
Stop	Stop / Hold	Repeat/Shuffle	Green / APP / Repeat
Menu	Menu / Home	Sleep/Timer	Sleep / Timer

Original		Replacement		Original	Replacement
DSC	DSC	OPT-TOOLS SETUP	Set up / OPT /		
DBB	DBB	TOP MENU D.MENU	D. Menu / Top		

Original	Replacement	Original	Replacement
Power	Power	Max	Smart / List
Open/Close	Eject / Surround	Vol -	Vol -
Up	Up	Vol +	Vol +
Preset/Album+	CH+ / Page+	1	1
I<<	I<< / Preset-	2	2
I<<	Left	3	3
Play/Pause	Play / Slow	4	4
Play/Pause	OK	5	5
Play/Pause	Pause / Step / Freeze	6	6
>>I	>>I / Preset+	7	7
>>I	Right	8	8
Preset/Album-	CH- / Page-	9	9
Down	Down	Prog/Clock Set	TV/Radio /
Disp	Display / Media	0	0
Mute	Mute / Dimmer	Repeat/Shuffle	Blue / Prime Video / Random
Stop	Stop / Hold	Repeat/Shuffle	Green / APP / Repeat
Menu	Menu / Home	Sleep/Timer	Sleep / Timer

Original		Replacement		Original	Replacement
DSC	DSC	OPT-TOOLS SETUP	Set up / OPT /		
DBB	DBB	TOP MENU D.MENU	D. Menu / Top		