Original		Replacement	
	Power		Power
	Tuner	SHIFT + 1	Shift + 1
	CD	SHIFT + 2	Shift + 2
	CDR / Tape	SHIFT + 3	Shift + 3
	VCR	SHIFT + 4	Shift + 4
	TV	SHIFT + 5	Shift + 5
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
CINEMA LINK	Cinema Link	APP MEDIA	Media

Original		Replacement	
DVD/6CH	DVD / 6 CH.	FAV PRE-CH	Pre Ch
MENU	Menu / Guide	TOP MENU MENU	Menu
MENU	Menu / Guide	GUIDE	Guide
OK	OK	OK	Ok
	Up		Up
	Right		Right
	Down		Down
	Left		Left
	Vol +	VOL +	Vol +
	Vol -	VOL -	Vol -
	Mute	MUTE	Mute
	Play	PLAY MODE	Play
	Stop		Stop
CHANNEL	I< Channel / Track		I<<
CHANNEL	Channel / Track >I		>>I
PAUSE	Pause		Pause
FR.D./INDEX	Disc / FR.D./Ind	HOME SMART	Smart

Original		Replacement		Original	Replacement
DISPLAY/T-C	Text / Display T-C	REPEAT TEXT	Text		
DISPLAY/T-C	Text / Display T-C	SHIFT + DISPLAY INFO	Shift + Info		
NEWS/TA	News / TA	DISPLAY INFO	Info		
SURR ON/OFF	Surr On / Off	C	Yellow		
SMART SOUND	Smart Sound	SOUND DUAL	Dual		
LOUDNESS	Loudness	A	Red		
REAR +	Rear Channel +	+ CH	Ch +		
REAR − CHANNEL	Rear Channel -	CH −	Ch -		
SURR MODE	Surr. Mode	D	Blue		
TEST TONE	Test Tone	B	Green		

Original		Replacement	
	Power Tv		Power
	TV	D	Blue
	Mute Tv	MUTE	Mute
1	1 Tv	1	1
2	2 Tv	2	2
3	3 Tv	3	3
4	4 Tv	4	4
5	5 Tv	5	5
6	6 Tv	6	6
7	7 Tv	7	7
8	8 Tv	8	8
9	9 Tv	9	9
0	0 Tv	0	0
MENU	Menu/Guide Tv	TOP MENU MENU	Menu
MENU	Menu/Guide Tv	GUIDE	Guide
OK	OK Tv	OK	Ok
	Up Tv		Up

Original		Replacement	
	Down Tv		Down
	Right Tv		Right
	Left Tv		Left
	Vol + Tv/CD	VOL +	Vol +
	Vol - Tv/CD	VOL −	Vol -
	Play Tv	PLAY MODE	Play
	Stop Tv		Stop
NEWS/TA	News/TA Tv	DISPLAY INFO	Info
CHANNEL	I< Channel/Track		I<<
CHANNEL/TRACK	Channel/Track >I		>>I
	Power CD	SHIFT +	Shift + Power
CD	CD	C	Yellow
	Mute CD	SHIFT + MUTE	Shift + Mute
1	1 CD	SHIFT + 1	Shift + 1
2	2 CD	SHIFT + 2	Shift + 2
3	3 CD	SHIFT + 3	Shift + 3
4	4 CD	SHIFT + 4	Shift + 4

Original		Replacement		Original	Replacement
5	5 CD	SHIFT + 5	Shift + 5		
6	6 CD	SHIFT + 6	Shift + 6		
7	7 CD	SHIFT + 7	Shift + 7		
8	8 CD	SHIFT + 8	Shift + 8		
9	9 CD	SHIFT + 9	Shift + 9		
0	0 CD	SHIFT + 0	Shift + 0		
	Up CD	SHIFT +	Shift + Up		
	Down CD	SHIFT +	Shift + Down		
	Right CD	SHIFT +	Shift + Right		
	Left CD	SHIFT +	Shift + Left		
NEWS/TA	News/TA CD	SHIFT + DISPLAY INFO	Shift + Info		
	Stop CD	SHIFT +	Shift + Stop		
	Play CD		Pause		
CHANNEL	I< CD		<<		
	>I CD		>>		
PAUSE	Pause CD	SHIFT +	Shift + Pause		
FR.D/INDEX DISC	Disc / FR. D. / Ind CD	HOME SMART	Smart		

Original		Replacement	
	Power VCR		Power
	VCR		Yellow
	Mute VCR	MUTE	Mute
1	1 VCR	1	1
2	2 VCR	2	2
3	3 VCR	3	3
4	4 VCR	4	4
5	5 VCR	5	5
6	6 VCR	6	6
7	7 VCR	7	7
8	8 VCR	8	8
9	9 VCR	9	9
0	0 VCR	0	0
MENU	Menu/Guide	TOP MENU MENU	Menu
	Up VCR		Up
OK	OK VCR	OK	Ok
	Down VCR		Down

Original		Replacement	
	Right VCR		Right
	Left VCR		Left
	Vol + VCR	+ VOL	Vol +
	Vol - VCR	VOL −	Vol -
	Play VCR	PLAY MODE ▶	Play
	Stop VCR	■	Stop
CHANNEL	I< Channel / Track VCR	⏮	I<<
CHANNEL/TRACK	Channel / Track >I VCR	⏭	>>I
PAUSE	Pause VCR	⏸	Pause
PR.D/INDEX DIGEST	T·C/Index VCR	RETURN BACK	Back
	Power	SHIFT +	Shift + Power
CDR/TAPE	CDR/Tape	D	Blue
1	1 CDR/Tape	SHIFT + 1	Shift + 1
2	2 CDR/Tape	SHIFT + 2	Shift + 2
3	3 CDR/Tape	SHIFT + 3	Shift + 3
4	4 CDR/Tape	SHIFT + 4	Shift + 4
5	5 CDR/Tape	SHIFT + 5	Shift + 5

Original		Replacement		Original	Replacement
6	6 CDR/Tape	SHIFT + 6	Shift + 6		
7	7 CDR/Tape	SHIFT + 7	Shift + 7		
8	8 CDR/Tape	SHIFT + 8	Shift + 8		
9	9 CDR/Tape	SHIFT + 9	Shift + 9		
0	0 CDR/Tape	SHIFT + 0	Shift + 0		
	Up CDR/Tape	SHIFT + ▲	Shift + Up		
	Down CDR/Tape	SHIFT + ▼	Shift + Down		
	Right CDR/Tape	SHIFT + ▶	Shift + Right		
	Left CDR/Tape	SHIFT + ◀	Shift + Left		
NEWS/TA	News/TA	DISPLAY INFO	Info		
CHANNEL	I< Channel/Track CDR/Tape	≪	<<		
CHANNEL	Channel/Track >I CDR/Tape	≫	>>		
PAUSE	Pause	SHIFT + ⏸	Shift + Pause		
DISC	Disc CDR/Tape	HOME SMART	Smart		