Original		Replacement	
TUNER	TUNER	SHIFT + TUNER 6	Shift + 6
CD	CD	SHIFT + CD - STB 3	Shift + 3
TAPE	TAPE	SHIFT + TAPE 5	Shift + 5
TV	TV	SHIFT + TV 1	Shift + 1
VCR	VCR	SHIFT + VIDEO 4	Shift + 4
1	TV 1	TV 1	1
2	TV 2	DVD 2	2
3	TV 3	CD - STB 3	3
4	TV 4	VIDEO 4	4
5	TV 5	TAPE 5	5
6	TV 6	TUNER 6	6
7	TV 7	AUX - HDD 7	7
8	TV 8	USB 8	8
9	TV 9	BLUETOOTH 9	9
MEMO	TV-TXT Memo	HOME MENU	Menu / Home
0	TV 0	HDMI - SAT 0	0
CLEAR -/--	TV -/--	-/-- GUIDE EPG	Guide / EPG / -/--

Original		Replacement	
B	Speakers B		Left
MODE RANDOM	TV Mode	OK	OK
A	Speakers A		Right
PRESET	TV Preset +	PRESET+	>>I / Preset+
PRESET	TXT Preset +	TUNE+	>> / Tune+
VOL.	Volume Audio +	VOL +	Vol +
VOL.	Volume TV +	CH PAGE +	CH+ / Page+
PRESET	TV Preset -	PRESET-	I<< / Preset-
PRESET	TXT Preset -	TUNE-	<< / Tune-
VOL.	Volume Audio -	VOL -	Vol -
VOL.	Volume TV -	CH PAGE -	CH- / Page-
STOP	TV-TXT Hold	HOLD	Stop / Hold
PLAY	TV-TXT Cancel	CLEAR EXIT CANCEL	Exit / Cancel / Clear
	TV-TXT Time	RETURN BACK	Back / Return
	TV-TXT Reveal	ANGLE INFO	Info / Angle
TXT	TXT	GOTO TEXT	Text / Goto
ST.BY	TV Standby		Power

Original		Replacement	
TUNER	TUNER	SHIFT + TUNER 6	Shift + 6
CD	CD	SHIFT + CD-STB 3	Shift + 3
TAPE	TAPE	SHIFT + TAPE 5	Shift + 5
TV	TV	SHIFT + TV 1	Shift + 1
VCR	VCR	SHIFT + VIDEO 4	Shift + 4
1	CD 1	TV 1	1
2	CD 2	DVD 2	2
3	CD 3	CD-STB 3	3
4	CD 4	VIDEO 4	4
5	CD 5	TAPE 5	5
6	CD 6	TUNER 6	6
7	CD 7	AUX-HDD 7	7
8	CD 8	USB 8	8
9	CD 9	BLUETOOTH 9	9
0	CD 0	HDMI-SAT 0	0
B	Speakers B		Left
MODE RANDOM	CD Mode	OK	OK

Original		Replacement	
A	Speakers A		Right
PRESET	CD Track +	PRESET+	>>I / Preset+
DISC	CD Disc +	CH PAGE +	CH+ / Page+
VOL.	Volume Audio +	VOL +	Vol +
PRESET	CD Track -	PRESET-	I<< / Preset-
DISC	CD Disc -	CH PAGE -	CH- / Page-
VOL.	Volume Audio -	VOL -	Vol -
STOP	CD Stop	HOLD	Stop / Hold
PAUSE	CD Pause	STEP-FREEZE	Pause / Step / Freeze
PLAY	CD Play	SLOW	Play / Slow
	CD <<	TUNE-	<< / Tune-
	CD >>	TUNE+	>> / Tune+
TXT	TXT	GOTO TEXT	Text / Goto
ST.BY	CD Standby		Power

Original	Replacement
TUNER	Shift + 6
CD	Shift + 3
TAPE	Shift + 5
TV	Shift + 1
VCR	Shift + 4
TUNER 1	1
TUNER 2	2
TUNER 3	3
TUNER 4	4
TUNER 5	5
TUNER 6	6
TUNER 7	7
TUNER 8	8
TUNER 9	9
TUNER 0	0
Speakers B	Left
TUNER Mode	OK

Original	Replacement
Speakers A	Right
TUNER Preset +	>>I / Preset+
Volume Audio +	Vol +
TUNER Preset -	I<< / Preset-
Volume Audio -	Vol -
TUNER <<	<< / Tune-
TUNER >>	>> / Tune+
TXT	Text / Goto
TUNER Standby	Power
TAPE Deck B	Shift + Left
TAPE Mode	Shift + OK
TAPE Deck A	Shift + Right
TAPE Preset +	Shift + >>I / Preset+
TAPE Preset -	Shift + I<< / Preset-
TAPE Stop	Shift + Stop /
TAPE Pause	Shift + Pause / Step /
TAPE Play	Shift + Play / Slow

Original	Replacement	Original	Replacement
TAPE <<	Shift + << /		
TAPE >>	Shift + >> /		
TAPE Record	Shift + Rec / Rec Mode		
TAPE Standby	Shift + Power		

Original		Replacement	
TUNER	TUNER	SHIFT + TUNER 6	Shift + 6
CD	CD	SHIFT + CD - STB 3	Shift + 3
TAPE	TAPE	SHIFT + TAPE 5	Shift + 5
TV	TV	SHIFT + TV 1	Shift + 1
VCR	VCR	SHIFT + VIDEO 4	Shift + 4
VCR	VCR -/--	-/-- GUIDE EPG	Guide / EPG / -/--
1	VCR 1	TV 1	1
2	VCR 2	DVD 2	2
3	VCR 3	CD - STB 3	3
4	VCR 4	VIDEO 4	4
5	VCR 5	TAPE 5	5
6	VCR 6	TUNER 6	6
7	VCR 7	AUX - HDD 7	7
8	VCR 8	USB 8	8
9	VCR 9	BLUETOOTH 9	9
0	VCR 0	HDMI - SAT 0	0
B	Speakers B	◀	Left

Original		Replacement	
MODE RANDOM	VCR Mode	OK	OK
A	Speakers A	▶	Right
PRESET	VCR Preset/Track	CH PAGE +	CH+ / Page+
PRESET	VCR Preset/Track	PRESET+ ▶▶I	>>I / Preset+
VOL.	Volume Audio +	VOL +	Vol +
PRESET	VCR Preset/Track	CH PAGE −	CH- / Page-
PRESET	VCR Preset/Track	PRESET- I◀◀	I<< / Preset-
VOL.	Volume Audio -	VOL −	Vol -
STOP	VCR Stop	HOLD ■	Stop / Hold
PAUSE	VCR Pause	STEP - FREEZE ⏸	Pause / Step / Freeze
PLAY	VCR Play	SLOW ▶	Play / Slow
	VCR <<	TUNE- ◀◀	<< / Tune-
	VCR >>	TUNE+ ▶▶	>> / Tune+
TXT	TXT	GOTO TEXT	Text / Goto
REC	VCR Record	REC MODE ●	Rec / Rec Mode
ST.BY	VCR Standby	⏻	Power