Original		Replacement		Original		Replacement	
STANDBY	Standby		Power	VOL-	Vol -	VOL −	Vol -
MUTE	Mute	DIMMER MUTE	Mute / Dimmer	VOL+	Vol +	+ VOL	Vol +
EPG	EPG	-/-- GUIDE EPG	Guide / EPG / -/--	FAVOURITE	Favourite	PC FAV MARKER	Fav / Marker / PC
INFO	Info	ANGLE INFO	Info / Angle	TV/RADIO	Tv/Radio	PROGRAM TV/RADIO	TV/Radio /
TTX	TTX	GOTO TEXT	Text / Goto	1	1	TV 1	1
AUDIO	Audio	LANG I/II AUDIO	Audio / Lang I/II	2	2	DVD 2	2
DTV/VCR	DTV/VCR	LIST SMART	Smart / List	3	3	CD - STB 3	3
SUBTITLE	Subtitle	EQ SUBTITLE	Subtitle / EQ	RECALL	Recall	RETURN BACK	Back / Return
MENU	Menu	HOME MENU	Menu / Home	4	4	VIDEO 4	4
CH+	UP		Up	5	5	TAPE 5	5
CH-	Down		Down	6	6	TUNER 6	6
VOL+	Right		Right	GOTO	Goto	SHIFT + GOTO TEXT	Shift + Text /
VOL-	Left		Left	7	7	AUX - HDD 7	7
OK	OK	OK	OK	8	8	USB 8	8
CH+	CH+	+ CH PAGE	CH+ / Page+	9	9	BLUETOOTH 9	9
CH-	CH-	CH PAGE −	CH- / Page-	0	0	HDMI - SAT 0	0
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear	REV	<<	TUNE-	<< / Tune-

Original		Replacement	
FWD	>>	TUNE+	>> / Tune+
PREV	I<<	PRESET-	I<< / Preset-
NEXT	>>I	PRESET+	>>I / Preset+
PLAY	Play	SLOW	Play / Slow
PAUSE	Pause	STEP-FREEZE	Pause / Step / Freeze
STOP	Stop	HOLD	Stop / Hold
REPEAT	Repeat	SHIFT + APP REPEAT	Shift + Green / APP /
	Red	NETFLIX SEARCH	Red / Netflix / Search
	Green	APP REPEAT	Green / APP / Repeat
	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat
	Blue	Prime Video RANDOM	Blue / Prime Video / Random

Original	Replacement