Original		Replacement	
	Power		Power
	Mute		Mute / Dimmer
	Play		Play / Slow
	Pause		Pause / Step / Freeze
	Stop		Stop / Hold
	Rec		Rec / Rec Mode
	<<		<< / Tune-
	I<<		I<< / Preset-
	>>I		>>I / Preset+
	>>		>> / Tune+
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7

Original		Replacement	
8	8	8	8
9	9	9	9
	Recall		Back / Return
0	0	0	0
EPG	EPG		Guide / EPG / -/--
MENÚ	Menu		Menu / Home
	Sources		AV / Input / RDS
	Up		Up
	Left		Left
	OK	OK	OK
	Right		Right
	Down		Down
INFO	Info		Info / Angle
EXIT	Exit		Exit / Cancel / Clear
	Smart		Smart / List
	Vol +		Vol +
P	P+		CH+ / Page+

Original		Replacement		Original		Replacement
	Vol -	VOL	Vol -			
	Home	SHIFT + HOME MENU	Shift + Menu /			
P	P-	CH PAGE	CH- / Page-			
NETFLIX	Netflix	SHIFT + NETFLIX SEARCH	Shift + Red / Netflix /			
YouTube	YouTube	SHIFT + YouTube REPEAT A-B	Shift + Yellow / YouTube /			
	Red	NETFLIX SEARCH	Red / Netflix / Search			
	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat			
	Green	APP REPEAT	Green / APP / Repeat			
	Blue	Prime Video RANDOM	Blue / Prime Video / Random			
V.O.	V.O.	LANG I/II AUDIO	Audio / Lang I/II			
	[≡]	GOTO TEXT	Text / Goto			
SUBT	Subt.	EQ SUBTITLE	Subtitle / EQ			