Original		Replacement	
	Power		Power
	Up		Up
	Left		Left
	Right		Right
	Down		Down
M	M	HOME MENU	Menu / Home
	[i]	ANGLE INFO	Info / Angle
OK	OK	OK	OK
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9

Original		Replacement	
PP	PP	RETURN BACK	Back / Return
0	0	HDMI - SAT 0	0
-/--	-/--	-/-- GUIDE EPG	Guide / EPG / -/--
P<P	P<P	PC FAV MARKER	Fav / Marker / PC
P/CH	P/CH-	CH PAGE −	CH- / Page-
P/CH	P/CH+	+ CH PAGE	CH+ / Page+
	Vol -	VOL −	Vol -
	Vol +	+ VOL	Vol +
	Mute	DIMMER MUTE	Mute / Dimmer
I-II	I-II	LANG I/II AUDIO	Audio / Lang I/II
TV	TV	LIST SMART	Smart / List
AV	AV	RDS AV INPUT	AV / Input / RDS
SOUND	Red/Sound	NETFLIX SEARCH	Red / Netflix / Search
SOUND	Red/Sound	TITLE SOUND	Sound / Title
PICTURE	Green/Picture	APP REPEAT	Green / APP / Repeat
PICTURE	Green/Picture	FORMAT PICTURE	Picture / Format
FEATURE	Yellow/Feature	YouTube REPEAT A-B	Yellow / YouTube / Repeat

Original		Replacement		Original		Replacement
INSTALL	Blue/Install	Prime Video / RANDOM	Blue / Prime Video / Random			
	[≡]	GOTO / TEXT	Text / Goto			
	[≡o]	TIMER / SLEEP	Sleep / Timer			
	[≡+]	HOLD	Stop / Hold			
	[≡x] / [· ·]	TUNE-	<< / Tune-			
	[/≡] / [*]	SLOW	Play / Slow			
	[≡♦] / [+]	STEP-FREEZE	Pause / Step / Freeze			
PC	[≡?] / PC	SHIFT + PC / FAV MARKER	Shift + Fav / Marker / PC			
	[≡]	TUNE+	>> / Tune+			