Original	Replacement	Original	Replacement
Power	Power	Blue / Title	Blue
HDMI Control	Smart	1	1
Rec	Rec	2	2
Play	Play	3	3
Pause	Pause	4	4
Stop	Stop	5	5
I<<	I<<	6	6
<<	<<	7	7
>>	>>	8	8
>>I	>>I	9	9
Screen	Format	0	0
Lang	Dual	Text	Text
Subtitle	Subt	Swap	Pre Ch
PIP / World	3D	Up	Up
Red / Zoom	Red	Right	Right
Green / Repeat	Green	Down	Down
Yellow / Root	Yellow	Left	Left

Original		Replacement		Original		Replacement	
OK	OK	OK	Ok				
P/CH +	P/CH +	CH +	Ch +				
P/CH -	P/CH -	CH -	Ch -				
Mute	Mute	MUTE	Mute				
Vol +	Vol +	VOL +	Vol +				
Vol -	Vol -	VOL -	Vol -				
MENU	Menu	TOP MENU MENU	Menu				
SOURCE	Source	TIMER AV	AV				
RETURN	Return	RETURN BACK	Back				
EPG	EPG	-/-- GUIDE	Guide				
INFO	Info	DISPLAY INFO	Info				
SLEEP	Sleep	PROG SLEEP	Sleep				
FAV	FAV	SHIFT + FAV PRE-CH	Shift + Pre Ch				
	Angle / Media	APP MEDIA	Media				
SEARCH MODE	Search Mode	SEARCH TV/R	TV/R				
DISPLAY	Display	SHIFT + DISPLAY INFO	Shift + Info				
PRESETS	Presets	DISC NAV LIST	List				