Original	Rechange	Original	Rechange
Sleep	Sleep / Timer	Muting	Mute / Dimmer
On	Power	Level Down	CH- / Page-
Standby	Shift + Power	Level Up	CH+ / Page+
Return	Back / Return	I<<	I<< / Preset-
Setup	Setup / OPT /	Play	Play / Slow
Disc+	Shift + CH+ /	>>I	>>I / Preset+
Up	Up	<<	<< / Tune-
Vol +	Vol +	Stop	Stop / Hold
Disc-	Shift + CH- /	>>	>> / Tune+
Left	Left	Random	Blue / Prime Video / Random
Enter	OK	Pause / Play Rev	Pause / Step / Freeze
Right	Right	Open / Close	Eject / Surround
Vol -	Vol -	Input Sel. DVD	Shift + 2
Down	Down	Input Sel. CD	Shift + 3
Audio	Audio / Lang I/II	Input Sel. V1	Shift + 1
CH Sel / Top Menu	D.Menu / Top	Input Sel. V2	Shift + 4
Test / Menu	Menu / Home	Input Sel. T1	Shift + 5

Original	Rechange
Input Sel. T2	Shift + 8
Input Sel. V3	Shift + 7
Input Sel. V4	Shift + Guide / EPG / -/--
Input Sel. TUN	Shift + 6
Input Sel. PH	Shift + 9
Stereo	1
Direct	2
DSP ▶	3
SURR	4
SURR	Shift + Eject / Surround
A.ST	5
◀ DSP	6
SP A	7
SP B	8
Re-EQ	9
Re-EQ	Subtitle / EQ
Display	Display / Media

Original	Rechange
Display	Guide / EPG / -/--
Dimmer	Shift + Mute / Dimmer
Dimmer	0
Zone 2	Fav / Marker / PC

Original		Rechange	
ON	ON	Power	Power
STDBY	STDBY	SHIFT + Power	Shift + Power
Return	RETURN	BACK	Back / Return
Setup	SETUP	OPT-TOOLS SETUP	Setup / OPT /
Disc+	CH DISC	CH PAGE +	CH+ / Page+
Up		Up	Up
Vol +	VOL	VOL +	Vol +
Disc-	CH DISC	CH PAGE −	CH- / Page-
Left		Left	Left
Enter	ENTER	OK	OK
Right		Right	Right
Vol -	VOL	VOL −	Vol -
Down		Down	Down
Top Menu	CH SEL TOP MENU	TOP MENU D.MENU	D.Menu / Top
Menu	TEST MENU	HOME MENU	Menu / Home
Muting	MUTING M	DIMMER MUTE	Mute / Dimmer
Angle	ANGLE LEVEL	ANGLE INFO	Info / Angle

Original		Rechange	
Subtitle	SUBTITLE LEVEL	EQ SUBTITLE	Subtitle / EQ
I<<		PRESET-	I<< / Preset-
Play		SLOW	Play / Slow
>>I		PRESET+	>>I / Preset+
<<		TUNE-	<< / Tune-
Stop		HOLD	Stop / Hold
>>		TUNE+	>> / Tune+
Random	RANDOM REC	Prime Video RANDOM	Blue / Prime Video / Random
Pause		STEP-FREEZE	Pause / Step / Freeze
Open / Close	OPEN/CLOSE	SURROUND	Eject / Surround
1	1 STEREO	TV 1	1
2	2 DIRECT	DVD 2	2
3	3 DSP	CD-STB 3	3
4	4 SURR	VIDEO 4	4
5	5 A.ST	TAPE 5	5
6	6 DSP	TUNER 6	6
7	7 SP A	AUX-HDD 7	7

Original		Rechange		Original	Rechange
8 SP B	8	USB 8	8		
9 Re-EQ	9	BLUETOOTH 9	9		
+10 DISPLAY --/---	+10	-/-- GUIDE EPG	Guide / EPG / -/--		
0 DIMMER	0	HDMI - SAT 0	0		
SEARCH ZONE 2 ENTER	Search	NETFLIX SEARCH	Red / Netflix / Search		

Original		Rechange	
ON	ON	Power	Power
STDBY	STDBY	SHIFT + Power	Shift + Power
Disc+	CH DISC	CH+ / Page+	CH+ / Page+
Vol +	VOL	Vol +	Vol +
Vol -	VOL	Vol -	Vol -
Muting	MUTING	Mute / Dimmer	Mute / Dimmer
I<<	I<<	I<< / Preset-	I<< / Preset-
Play	Play	Play / Slow	Play / Slow
>>I	>>I	>>I / Preset+	>>I / Preset+
<<	<<	<< / Tune-	<< / Tune-
Stop	Stop	Stop / Hold	Stop / Hold
>>	>>	>> / Tune+	>> / Tune+
Random	RANDOM	Blue / Prime Video / Random	Blue / Prime Video / Random
Pause	Pause	Pause / Step / Freeze	Pause / Step / Freeze
Open / Close	OPEN/CLOSE	Eject / Surround	Eject / Surround
1	1	1	1
2	2	2	2

Original		Rechange	
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
+10	+10	GUIDE EPG	Guide / EPG / -/--
0	0	0	0

Original		Rechange	
ON	ON	Power	Power
STDBY	STDBY	SHIFT + Power	Shift + Power
Vol +	VOL	Vol +	Vol +
Enter	ENTER	OK	OK
Vol -	VOL	VOL −	Vol -
Muting	MUTING	DIMMER MUTE	Mute / Dimmer
I<<	I<<	PRESET-	I<< / Preset-
Play	Play	SLOW	Play / Slow
>>I	>>I	PRESET+	>>I / Preset+
<<	<<	TUNE-	<< / Tune-
Stop	Stop	HOLD	Stop / Hold
>>	>>	TUNE+	>> / Tune+
Rec / Random	RANDOM REC	REC MODE	Rec / Rec Mode
Rec / Random	RANDOM REC	Prime Video RANDOM	Blue / Prime Video / Random
Pause	Pause	STEP-FREEZE	Pause / Step / Freeze
Open / Close	OPEN/CLOSE	SURROUND	Eject / Surround
1	1 STEREO	TV 1	1

Original		Rechange	
2	2 DIRECT	DVD 2	2
3	3 DSP	CD-STB 3	3
4	4 SURR	VIDEO 4	4
5	5 A.ST	TAPE 5	5
6	6 DSP	TUNER 6	6
7	7 SP A	AUX-HDD 7	7
8	8 SP B	USB 8	8
9	9 Re-EQ	BLUETOOTH 9	9
+10	+10 DISPLAY	-/-- GUIDE EPG	Guide / EPG / -/--
0	0 DIMMER	HDMI-SAT 0	0
SEARCH	SEARCH ZONE 2 ENTER	PC FAV MARKER	Fav / Marker / PC