Mandis shop

Denon RC-282

Original	Rechange	Original	Rechange
Power	Power	Rec	Rec
1	1	>>I	>>I
2	2	I <<	I <<
3	3	>>	>>
4	4	<<	<<
5	5	Clear	Exit
6	6	Group/Prog/Direct	Options
7	7	Repeat	Text
8	8	Random	Media
9	9	Edit	TV/R
10	0	Enter	Ok
+10	Guide	Title	Info
Call	Back	Character	Smart
Eject	Eject	Time	AV
Play	Play		
Pause	Pause		
Stop	Stop		