| Original | | Rechange | |
|---|---|---|---|
| STANDBY | Standby | | Power |
| MUTE | Mute | MUTE | Mute |
| | Up | | Up |
| | Left | | Left |
| OK | OK | OK | Ok |
| | Right | | Right |
| | Down | | Down |
| MENU | Menu | TOP MENU MENU | Menu |
| EXIT | Exit | CLEAR EXIT | Exit |
| UHF | Red / UHF | A | Red |
| AUDIO | Green / Audio | B | Green |
| AUDIO | Green / Audio | SOUND DUAL | Dual |
| PAUSE | Yellow / Pause | C | Yellow |
| PAUSE | Yellow / Pause | II | Pause |
| RECALL | Blue / Recall | D | Blue |
| RECALL | Blue / Recall | RETURN BACK | Back |
| 1 | 1 | 1 | 1 |

| Original | | Rechange | |
|---|---|---|---|
| 2 | 2 | 2 | 2 |
| 3 | 3 | 3 | 3 |
| 4 | 4 | 4 | 4 |
| 5 | 5 | 5 | 5 |
| 6 | 6 | 6 | 6 |
| 7 | 7 | 7 | 7 |
| 8 | 8 | 8 | 8 |
| 9 | 9 | 9 | 9 |
| 0 | 0 | 0 | 0 |
| EPG | EPG | -/-- GUIDE | Guide |
| GROUP | Group | FAV PRE-CH | Pre Ch |
| VOL | Vol + | VOL + | Vol + |
| VOL | Vol - | VOL − | Vol - |
| CH | CH+ | CH + | Ch + |
| CH | CH- | CH − | Ch - |
| PAGE | Page+ | >>I | >>I |
| PAGE | Page- | I<< | I<< |

| Original | Rechange | Original | Rechange |
|---|---|---|---|
| INFO Info | DISPLAY INFO Info | | |
| SAT/TV SAT/TV | TIMER AV AV | | |
| SAT/TV SAT/TV | APP MEDIA Media | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |