Original	Rechange
Standby FM-AM	Power
Volume Down	Vol -
Volume Up	Vol +
L FM-AM	Left
R FM-AM	Right
Front	Up
Rear	Down
1 FM-AM	1
2 FM-AM	2
3 FM-AM	3
4 FM-AM	4
5 FM-AM	5
6 FM-AM	6
7 FM-AM	7
8 FM-AM	8
9 FM-AM	9
10/0 FM-AM	0

Original	Rechange
AMS/-/-- FM-AM	Guide / EPG / -/--
Memo/CH/PGM	Fav / Marker / PC
+ FM-AM	CH+ / Page+
- FM-AM	CH- / Page-
Mute FM-AM	Mute / Dimmer
Mode FM-AM	D.Menu / Top
Deck A	Red / Netflix / Search
Deck B	Green / APP / Repeat
FM/AM	Blue / Prime Video / Random
CD	Yellow / YouTube / Repeat
TV	TV/Radio /
VCR	Smart / List
Phono	Zoom / Size
Tape	Display / Media
CDV	AV / Input / RDS
1 Phono	Shift + 1
2 Phono	Shift + 2

Original	Rechange
3 Phono	Shift + 3
4 Phono	Shift + 4
5 Phono	Shift + 5
6 Phono	Shift + 6
7 Phono	Shift + 7
8 Phono	Shift + 8
9 Phono	Shift + 9
10/0 Phono	Shift + 0
Memo/CH/PGM	Shift + Fav / Marker / PC
Mute Phono	Shift + Mute / Dimmer
Play Phono	Play / Slow
<< Phono	<< / Tune-
>> Phono	>> / Tune+
Pause Phono	Pause / Step / Freeze
Stop Phono	Stop / Hold
L Phono	Shift + Left
R Phono	Shift + Right

Original	Rechange
Volume Up	Shift + Vol +
Volume Down	Shift + Vol -

Original		Rechange	
STANDBY	Stanby CD		Power
DOWN	Volume Down	VOL −	Vol -
UP	Volume Up CD	+ VOL	Vol +
CD	CD	YouTube REPEAT A-B	Yellow / YouTube / Repeat
DECK A	Deck A	NETFLIX SEARCH	Red / Netflix / Search
DECK B	Deck B	APP REPEAT	Green / APP / Repeat
FM/AM	FM/AM	Prime Video RANDOM	Blue / Prime Video / Random
VCR	VCR	LIST SMART	Smart / List
TV	TV	PROGRAM TV/RADIO	TV/Radio /
TAPE	Tape	MEDIA DISPLAY	Display / Media
PHONO	Phono	SIZE ZOOM	Zoom / Size
CDV	CDV	RDS AV INPUT	AV / Input / RDS
L	L CD		Left
R	R CD		Right
+	+ CD	+ CH PAGE	CH+ / Page+
−	- CD	CH PAGE −	CH- / Page-
MUTE	Mute CD	DIMMER MUTE	Mute / Dimmer

Original		Rechange	
1	1 CD	TV 1	1
2	2 CD	DVD 2	2
3	3 CD	CD-STB 3	3
4	4 CD	VIDEO 4	4
5	5 CD	TAPE 5	5
6	6 CD	TUNER 6	6
7	7 CD	AUX-HDD 7	7
8	8 CD	USB 8	8
9	9 CD	BLUETOOTH 9	9
10/0	10/0	HDMI-SAT 0	0
AMS -/--	AMS/-/-- CD	-/-- GUIDE EPG	Guide / EPG / -/--
MEMO CH/PGM	Memo/CH/PGM	PC FAV MARKER	Fav / Marker / PC
	Play CD	SLOW ▶	Play / Slow
	Pause CD	STEP-FREEZE ⏸	Pause / Step / Freeze
	Stop CD	HOLD ■	Stop / Hold
	<< CD	TUNE- ◀◀	<< / Tune-
	>> CD	TUNE+ ▶▶	>> / Tune+

Original	Rechange
Standby VCR	Shift + Power
Volume Down	Shift + Vol -
Volume Up VCR	Shift + Vol +
L VCR	Shift + Left
R VCR	Shift + Right
+ VCR	Shift + CH+ /
- VCR	Shift + CH- /
Mute VCR	Shift + Mute / Dimmer
Mode VCR	Shift + D. Menu / Top Menu
1 VCR	Shift + 1
2 VCR	Shift + 2
3 VCR	Shift + 3
4 VCR	Shift + 4
6 VCR	Shift + 6
5 VCR	Shift + 5
7 VCR	Shift + 7
8 VCR	Shift + 8

Original	Rechange
9 VCR	Shift + 9
10/0 VCR	Shift + 0
AMS/-/-- VCR	Shift + Guide / EPG / -/--
Memo/CH/PGM	Shift + Fav / Marker / PC
Play VCR	Shift + Play /
Pause VCR	Shift + Pause / Step /
Stop VCR	Shift + Stop /
<> VCR	Shift + >>I / Preset+
>> VCR	Shift + >> /
<< VCR	Shift + << /
Rec VCR	Shift + Rec / Rec Mode

Original		Rechange	
STANDBY	Standby		Power
UP	Volume Up	VOL +	Vol +
DOWN	Volume Down	VOL –	Vol -
DECK A	Deck A	NETFLIX SEARCH	Red / Netflix / Search
DECK B	Deck B	APP REPEAT	Green / APP / Repeat
L	L		Left
R	R		Right
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
10/0	10/0	HDMI - SAT 0	0

Original		Rechange	
+	+	CH PAGE +	CH+ / Page+
–	-	CH PAGE –	CH- / Page-
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
AMS	AMS/--/-	-/-- GUIDE EPG	Guide / EPG / -/--
MEMO CH/PGM	Memo/CH/PGM	PC FAV MARKER	Fav / Marker / PC
	Play	SLOW ▶	Play / Slow
	Pause	STEP-FREEZE ⏸	Pause / Step / Freeze
	>>	TUNE+ ▶▶	>> / Tune+
	<<	TUNE- ◀◀	<< / Tune-
REC	Rec	REC MODE ●	Rec / Rec Mode
	Stop	HOLD ■	Stop / Hold
	<>	PRESET- ⏮	I<< / Preset-
CD	CD	YouTube REPEAT A-B	Yellow / YouTube / Repeat
FM/AM	FM/AM	Prime Video RANDOM	Blue / Prime Video / Random
TV	TV	PROGRAM TV/RADIO	TV/Radio /
VCR	VCR	LIST SMART	Smart / List
TAPE	Tape	MEDIA DISPLAY	Display / Media

Original	Rechange	Original	Rechange
PHONO Phono	SIZE ZOOM Zoom / Size		
CDV CDV	RDS AV INPUT AV / Input / RDS		

Original	Rechange	Original	Rechange
Deck A	Red / Netflix / Search	Mode TV	Shift + D.Menu / Top Menu
Deck B	Green / APP / Repeat	1 TV	Shift + 1
FM/AM	Blue / Prime Video / Random	2 TV	Shift + 2
CD	Yellow / YouTube / Repeat	3 TV	Shift + 3
TV	TV/Radio /	4 TV	Shift + 4
Tape	Display / Media	5 TV	Shift + 5
VCR	Smart / List	6 TV	Shift + 6
CDV	AV / Input / RDS	7 TV	Shift + 7
Phono	Zoom / Size	8 TV	Shift + 8
Standby TV	Shift + Power	9 TV	Shift + 9
Volume Down	Shift + Vol -	10/0 TV	Shift + 0
Volume Up TV	Shift + Vol +	Memo/CH/PGM	Shift + Fav / Marker / PC
L TV	Shift + Left	AMS/-/-- TV	Shift + Guide / EPG / -/--
R TV	Shift + Right	Standby CDV	Power
+ TV	Shift + CH+ /	Volume Up CVD	Vol +
- TV	Shift + CH- /	Volume Down	Vol -
Mute TV	Shift + Mute / Dimmer	L CDV	Left

Original	Rechange	Original	Rechange
R CDV	Right	Pause CDV	Pause / Step / Freeze
+ CDV	CH+ / Page+	Stop CDV	Stop / Hold
- CDV	CH- / Page-	<< CDV	<< / Tune-
Mute CDV	Mute / Dimmer	>> CDV	>> / Tune+
Mode CDV	D.Menu / Top		
1 CDV	1		
2 CDV	2		
3 CDV	3		
4 CDV	4		
5 CDV	5		
6 CDV	6		
7 CDV	7		
8 CDV	8		
9 CDV	9		
10/0 CDV	0		
Play CDV	Play / Slow		
Memo/CH/PGM	Fav / Marker / PC		