Original		Rechange	
TV Direct		Smart / List	
Power DVD		Red / Netflix / Search	
Power VCR		Green / APP / Repeat	
Power Audio		Power	
Power STB		Yellow / YouTube / Repeat	
Power TV		Blue / Prime Video / Random	
DVD		2	
VCR		4	
TV		1	
FM/AM		6	
Tv/Video		5	
Muting		Mute / Dimmer	
Channel +		CH+ / Page+	
Volume+		Vol +	
Channel -		CH- / Page-	
Volume-		Vol -	
Display/On Screen		Display / Media	

Original		Rechange	
Dimmer		Shift + Mute / Dimmer	
Sleep		Sleep / Timer	
Analog/Digital Input		AV / Input / RDS	
Smart S Setup		Setup / OPT /	
Bass Boost		Audio / Lang I/II	
C. Tone		Subtitle / EQ	
A. Position		D.Menu / Top	
Test Tone		Text / Goto	
Effect		Info / Angle	
Decode		TV/Radio /	
Surround		Eject / Surround	
Subwfr+		Right	
Center+		Up	
Surr L+		Shift + Vol +	
Surr R+		Shift + CH+ /	
Subwfr-		Left	
Center-		Down	

Original	Rechange	Original	Rechange
Surr L-	SHIFT + VOL - : Shift + Vol -		
Surr R-	SHIFT + CH PAGE - : Shift + CH- /		

Original		Rechange	
	Power Audio		Power
	Power Tv	SHIFT +	Shift + Power
	FM/AM	SURROUND	Eject / Surround
	Tv Vol +	VOL +	Vol +
	Channel + TV	CH PAGE +	CH+ / Page+
	Tv Vol -	VOL −	Vol -
	Channel - TV	CH PAGE −	CH- / Page-
	Tuning- FM/AM	TUNE-	<< / Tune-
	FM Mode FM/AM	LIST SMART	Smart / List
	Tuning+ FM/AM	TUNE+	>> / Tune+
	Memory FM/AM	HOME MENU	Menu / Home
	TA/News/Info	ANGLE INFO	Info / Angle
	TA/News/Info		Up
	PTY- FM/AM		Left
	PTY+ FM/AM		Right
	PTY Search		Down
	PTY Search	NETFLIX SEARCH	Red / Netflix / Search

Original		Rechange	
	Display FM/AM	MEDIA DISPLAY	Display / Media
1	1 FM/AM	SHIFT + TV 1	Shift + 1
1	1 TV	TV 1	1
2	2 FM/AM	SHIFT + DVD 2	Shift + 2
2	2 TV	DVD 2	2
3	3 FM/AM	SHIFT + CD-STB 3	Shift + 3
3	3 TV	CD-STB 3	3
4	4 FM/AM	SHIFT + VIDEO 4	Shift + 4
4	4 TV	VIDEO 4	4
5	5 FM/AM	SHIFT + TAPE 5	Shift + 5
5	5 TV	TAPE 5	5
6	6 FM/AM	SHIFT + TUNER 6	Shift + 6
6	6 TV	TUNER 6	6
7	7 FM/AM	SHIFT + AUX-HDD 7	Shift + 7
7	7 TV	AUX-HDD 7	7
8	8 FM/AM	SHIFT + USB 8	Shift + 8
8	8 TV	USB 8	8

Original		Rechange		Original		Rechange
9	9 FM/AM	SHIFT + BLUETOOTH 9	Shift + 9			
9	9 TV	BLUETOOTH 9	9			
TV RETURN 10	10 FM/AM	SHIFT + PC FAV MARKER	Shift + Fav / Marker / PC			
TV RETURN 10	10/Tv Return TV	SHIFT + HDMI - SAT 0	Shift + 0			
0	0 TV	HDMI - SAT 0	0			
100+ +10	+10/100+	SHIFT + -/-- GUIDE EPG	Shift + Guide / EPG / -/--			
100+ +10	+10 TV	PC FAV MARKER	Fav / Marker / PC			

Original		Rechange	
	Power DVD		Power
	I<<	PRESET-	I<< / Preset-
	Play	SLOW	Play / Slow
	>>I	PRESET+	>>I / Preset+
	<<	TUNE-	<< / Tune-
	Stop	HOLD	Stop / Hold
	Pause	STEP-FREEZE	Pause / Step / Freeze
	Top Menu	TOP MENU D.MENU	D.Menu / Top
	>>	TUNE+	>> / Tune+
	Up		Up
	Menu	HOME MENU	Menu / Home
	Left	SHIFT +	Shift + Left
	Enter	OK	OK
	Right		Right
	Set Up	OPT-TOOLS SETUP	Setup / OPT /
	Down		Down
	On Screen	SHIFT + MEDIA DISPLAY	Shift + Display / Media

Original		Rechange	
	Audio	LANG I/II AUDIO	Audio / Lang I/II
	Subtitle	EQ SUBTITLE	Subtitle / EQ
	Title Group	SHIFT + TITLE SOUND	Shift + Sound / Title
	Return	RETURN BACK	Back / Return
	DVD Zoom	SIZE ZOOM	Zoom / Size
	1	TV 1	1
	2	DVD 2	2
	3	CD-STB 3	3
	VFP Progressive	LIST SMART	Smart / List
	4	VIDEO 4	4
	5	TAPE 5	5
	6	TUNER 6	6
	←		Left
	7	AUX-HDD 7	7
	8	USB 8	8
	9	BLUETOOTH 9	9
	Angle	ANGLE INFO	Info / Angle

Original		Rechange		Original	Rechange
TV RETURN 10	10	GUIDE EPG	Guide / EPG / -/--		
0	0	HDMI - SAT 0	0		
100+ +10	+10	PC FAV MARKER	Fav / Marker / PC		
DIMMER	Display/Dimmer	MEDIA DISPLAY	Display / Media		
ANALOG/DIGITAL INPUT	Input Analog/Digital	RDS AV INPUT	AV / Input / RDS		
CANCEL	Cancel	CLEAR EXIT CANCEL	Exit / Cancel / Clear		
EFFECT	HDD Sound Effect	TITLE SOUND	Sound / Title		
SURROUND	Surround	SURROUND	Eject / Surround		

Original		Rechange	
Power VCR		SHIFT +	Shift + Power
Power STB			Power
VCR		SHIFT + GUIDE EPG	Shift + Guide / EPG / -/--
Muting		DIMMER MUTE	Mute / Dimmer
Channel +		CH PAGE +	CH+ / Page+
Volume+		VOL +	Vol +
Channel -		CH PAGE −	CH- / Page-
Volume-		VOL −	Vol -
Play VCR		SLOW ▶	Play / Slow
<< VCR		TUNE- ◀◀	<< / Tune-
Stop/Memory		HOLD ■	Stop / Hold
Pause VCR		STEP-FREEZE ⏸	Pause / Step / Freeze
>> VCR		TUNE+ ▶▶	>> / Tune+
1 VCR		SHIFT + TV 1	Shift + 1
1 STB		TV 1	1
2 VCR		SHIFT + DVD 2	Shift + 2
2 STB		DVD 2	2

Original		Rechange	
3 VCR		SHIFT + CD-STB 3	Shift + 3
3 STB		CD-STB 3	3
4 VCR		SHIFT + VIDEO 4	Shift + 4
4 STB		VIDEO 4	4
5 VCR		SHIFT + TAPE 5	Shift + 5
5 STB		TAPE 5	5
6 VCR		SHIFT + TUNER 6	Shift + 6
6 STB		TUNER 6	6
7 VCR		SHIFT + AUX-HDD 7	Shift + 7
7 STB		AUX-HDD 7	7
8 VCR		SHIFT + USB 8	Shift + 8
8 STB		USB 8	8
9 VCR		SHIFT + BLUETOOTH 9	Shift + 9
9 STB		BLUETOOTH 9	9
TV RETURN 10	+10 TV	-/-- GUIDE EPG	Guide / EPG / -/--
0 VCR		SHIFT + HDMI-SAT 0	Shift + 0
0 STB		HDMI-SAT 0	0